

Service Manual





Service Manual

Copyright and License

© 2010 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number: CE861-90939

Edition 1, 9/2010

Trademark Credits

Microsoft®, Windows®, Windows® XP, and Windows Vista® are U.S. registered trademarks of Microsoft Corporation.

ENERGY STAR and the ENERGY STAR mark are registered U.S. marks.

Conventions used in this guide

- ☆ TIP: Tips provide helpful hints or shortcuts.
- NOTE: Notes provide important information to explain a concept or to complete a task.
- △ CAUTION: Cautions indicate procedures that you should follow to avoid losing data or damaging the product.
- ⚠ WARNING! Warnings alert you to specific procedures that you should follow to avoid personal injury, catastrophic loss of data, or extensive damage to the product.

ENWW

Table of contents

1	Removal and replacement	1
	Introduction	2
	Removal and replacement strategy	2
	Electrostatic discharge	4
	Required tools	4
	Service approach	5
	Before performing service	5
	After performing service	6
	Post-service tests	6
	Test 1 (print-quality test)	e
	Test 2 (copy-quality test)	e
	Test 3 (fax-quality test)	6
	Parts removal order	7
	Removal and replacement procedures	8
	Pickup roller	8
	Separation roller	10
	Transfer roller	12
	Print-cartridge drawer	14
	Right cover	17
	Right-front cover-1 and cover-2	20
	Control panel	22
	Left cover	
	Document-feeder and scanner assembly	28
	Rear-center cover	30
	Rear-upper cover	31
	Speaker	33
	Top cover	
	Front door and front-lower cover	
	Rear door and rear-lower cover	41
	Main assemblies	
	Paper-guide assembly	
	USB port PCA and bracket	
	Reinstall the USB port PCA	
	Wireless PCA (wireless models only)	48

DC controller PCA	49
Special considerations	49
Remove the DC controller PCA	49
Formatter PCA, fax card PCA, and support bracket	53
Special considerations	
Remove the formatter PCA	53
Fuser motor	59
Main motor	60
Intermediate transfer belt (ITB)	62
Reinstall the ITB	65
Power supply (high-voltage)	67
Reinstall the power supply (high voltage)	70
Power supply (low voltage)	
Reinstall the power supply (low voltage)	75
Power supply (fuser)	77
Fuser	80
Document feeder components	83
Document feeder separation pad	83
Document feeder input tray	87
Document feeder cover	88
Document feeder pick arm assembly	90
Document feeder core assembly	92
Post scan pinch rollers	94
Document feeder base assembly	95
Document feeder floating hinges	97
2 Solve problems	99
Menu map	
Tools for troubleshooting	100
Component diagnostics	100
LED diagnostics	
Network LEDs	100
Control panel LEDs	101
Control-panel diagnostics	102
Engine Diagnostics	102
Engine test	102
Repetitive image defects	103
Diagrams	
Plug/jack locations	104
DC controller PCA	105
General timing charts (product base only)	107
General circuit diagram (product base only)	108
Print-quality troubleshooting tools	109

vi ENWW

Print a Diagnostics Page	109
Calibrate the product	. 109
Interpret the Print Quality Page	. 109
Control panel menus	. 111
Setup Menu	. 111
Reports menu	. 112
Quick Forms menu	. 113
Fax Setup menu	. 114
System Setup menu	. 117
Service menu	. 120
Network Setup menu	. 122
Function specific menus	. 123
Copy Menu	. 123
Fax Menu	. 124
Scan Menu	. 126
USB Flash Drive	. 127
Interpret control-panel messages	. 128
Control panel message types	. 128
Control panel messages	. 128
10.100X Supply Memory Error	. 128
49 Error, Turn off then on	. 128
50.x Fuser Error	. 128
79 Error Turn off then on	. 128
Communication error	. 128
Document feeder jam. Clear and reload	. 129
Document feeder mispick. Reload	. 129
Door open	. 129
Engine Communication Error	. 129
Engine error. Press OK to continue.	. 129
Fax receive error.	. 129
Fax Send error	. 130
Jam in (area), Open door and clear jam	. 130
Jam in Tray 1, Clear jam and then press OK	. 130
Load paper	. 130
No dial tone.	. 130
No fax answer. Canceled send	. 130
No fax answer. Redial pending	. 131
No fax detected.	. 131
Print failure, press OK. If error repeats, turn off then on	. 131
Scanner error #, Turn off then on	. 132
Scanning error Cannot connect	
Event-log messages	
Paper feeds incorrectly or becomes jammed	
The product does not pick up paper	

	The product picks up multiple sheets of paper	135
	Prevent paper jams	136
	Clear jams	136
	Jam locations	136
	Clear jams from the document feeder	137
	Clear jams from the input tray	139
	Clear jams from the output bin	142
	Service mode functions	143
	Secondary service menu	143
	Open the secondary service menu	143
	Secondary service menu structure	143
	Product resets	144
	Restore the factory-set defaults	144
	NVRAM initialization	145
	Solve fax problems	146
	Troubleshoot fax codes and trace reports	146
	View and interpret fax error codes	146
	Fax trace report	156
	Product updates	156
3 Pa	order parts by authorized service providers	
	Order replacement parts	
	Related documentation and software	
	Supplies part numbers	
	Service parts	
	Customer self repair parts	
	Whole-unit replacement part numbers	
	How to use the parts lists and diagrams	
	Assembly locations	
	Base product	
	Covers	
	Internal assemblies	
	Internal assemblies (1 of 4)	
	Internal assemblies (2 of 4)	
	Internal assemblies (3 of 4)	
	Internal assemblies (4 of 4)	
	PCAs	
	Scanner and document feeder (ADF) main assemblies	
	Document feeder internal components	
	Alphabetical parts list	
	Numerical parts list	

Appendix	x A Service and support	185
	Hewlett-Packard limited warranty statement	186
	HP's Premium Protection Warranty: LaserJet print cartridge limited warranty statement	187
	Data stored on the print cartridge	188
	End User License Agreement	189
	OpenSSL	191
	Customer support	191
	Repack the product	192
Appendi	x B Product specifications	193
	Physical specifications	194
	Power consumption, electrical specifications, and acoustic emissions	194
	Environmental specifications	194
Appendi	x C Regulatory information	195
	FCC regulations	196
	Environmental product stewardship program	197
	Protecting the environment	197
	Ozone production	197
	Power consumption	197
	Paper use	197
	Plastics	197
	HP LaserJet print supplies	197
	Return and recycling instructions	198
	United States and Puerto Rico	198
	Multiple returns (more than one cartridge)	198
	Single returns	198
	Shipping	198
	Non-U.S. returns	198
	Paper	199
	Material restrictions	199
	Disposal of waste equipment by users in private households in the European Union .	199
	Chemical substances	199
	Material Safety Data Sheet (MSDS)	200
	For more information	200
	Declaration of Conformity	201
	Declaration of Conformity (wireless models)	203
	Certificate of Volatility	205
	Safety statements	206
	Laser safety	206
	Canadian DOC regulations	206
	VCCI statement (Japan)	206
	Power cord instructions	206

ENWW

Power cord statement (Japan)	206
EMC statement (Korea)	207
Laser statement for Finland	207
GS statement (Germany)	207
Substances Table (China)	208
Restriction on Hazardous Substances statement (Turkey)	208
Additional statements for telecom (fax) products	209
EU Statement for Telecom Operation	209
New Zealand Telecom Statements	209
Additional FCC statement for telecom products (US)	209
Telephone Consumer Protection Act (US)	210
Industry Canada CS-03 requirements	210
Additional statements for wireless products	212
FCC compliance statement—United States	212
Australia statement	212
Brazil ANATEL statement	212
Canadian statements	212
European Union regulatory notice	212
Notice for use in France	213
Notice for use in Russia	213
Korean statement	213
Taiwan statement	213
Index	215

List of tables

Table 1-1	Components inspection	2
Table 2-1	Repetitive image defects	103
Table 2-2	DC controller connectors	105
Table 2-3	Event-log messages	133
Table 2-4	Secondary service menu	143
Table 2-5	Fax receive error codes	146
Table 2-6	Fax send error codes	150
Table 3-1	Order parts, accessories, and supplies	158
Table 3-2	Related documentation and software	158
Table 3-3	Supplies part numbers	158
Table 3-4	Service parts	158
Table 3-5	Customer replaceable units (CRU) kit part numbers	159
Table 3-6	Whole-unit replacement part numbers	159
Table 3-7	Base product	161
Table 3-8	Covers, panels, and doors	163
Table 3-9	Internal assemblies (1 of 4)	165
Table 3-10	Internal assemblies (2 of 4)	167
Table 3-11	Internal assemblies (3 of 4)	169
Table 3-12	Internal assemblies (4 of 4)	171
Table 3-13	PCAs	173
Table 3-14	Scanner and document feeder main assemblies	175
Table 3-15	Document feeder assembly parts	177
Table 3-16	Alphabetical parts list	178
Table 3-17	Numerical parts list	181
Table B-1	Physical specifications	194
Table B-2	Environmental specifications ¹	194

xii ENWW

List of figures

Figure 1-1	Phillips and Pozidrive screwdriver comparison	4
Figure 1-2	Parts-removal tree	7
Figure 1-3	Remove the pickup roller	9
Figure 1-4	Remove the separation roller (1 of 2)	10
Figure 1-5	Remove the separation roller (2 of 2)	11
Figure 1-6	Remove the transfer roller (1 of 3)	12
Figure 1-7	Remove the transfer roller (2 of 3)	12
Figure 1-8	Remove the transfer roller (3 of 3)	13
Figure 1-9	Remove the print-cartridge drawer (1 of 5)	14
Figure 1-10	Remove the print-cartridge drawer (2 of 5)	14
Figure 1-11	Remove the print-cartridge drawer (3 of 5)	15
Figure 1-12	Remove the print-cartridge drawer (4 of 5)	15
Figure 1-13	Remove the print-cartridge drawer (5 of 5)	16
Figure 1-14	Remove the right cover (1 of 5)	17
Figure 1-15	Remove the right cover (2 of 5)	17
Figure 1-16	Remove the right cover (3 of 5)	18
Figure 1-17	Remove the right cover (4 of 5)	18
Figure 1-18	Remove the right cover (5 of 5)	19
Figure 1-19	Remove the right-front cover (1 of 4)	20
Figure 1-20	Remove the right-front cover (2 of 4)	20
Figure 1-21	Remove the right-front cover (3 of 4)	21
Figure 1-22	Remove the right-front cover (4 of 4)	21
Figure 1-23	Remove the control panel (1 of 5)	22
Figure 1-24	Remove the control panel (2 of 5)	23
Figure 1-25	Remove the control panel (3 of 5)	23
Figure 1-26	Remove the control panel (4 of 5)	24
Figure 1-27	Remove the control panel (5 of 5)	24
Figure 1-28	Remove the left cover (1 of 6)	25
Figure 1-29	Remove the left cover (2 of 6)	25
Figure 1-30	Remove the left cover (3 of 6)	26
Figure 1-31	Remove the left cover (4 of 6)	26
Figure 1-32	Remove the left cover (5 of 6)	27
Figure 1-33	Remove the left cover (6 of 6)	27
Figure 1-34	Remove the document-feeder and scanner assembly (1 of 3)	28

Figure 1-35	Remove the document-feeder and scanner assembly (2 of 3)	28
Figure 1-36	Remove the document-feeder and scanner assembly (3 of 3)	29
Figure 1-37	Remove the rear-center cover (1 of 2)	30
Figure 1-38	Remove the rear-center cover (2 of 2)	30
Figure 1-39	Remove the rear-upper cover (1 of 4)	31
Figure 1-40	Remove the rear-upper cover (2 of 4)	31
Figure 1-41	Remove the rear-upper cover (3 of 4)	32
Figure 1-42	Remove the rear-upper cover (4 of 4)	32
Figure 1-43	Remove the speaker (1 of 2)	33
Figure 1-44	Remove the speaker (2 of 2)	33
Figure 1-45	Remove the top cover (1 of 3)	34
Figure 1-46	Remove the top cover (2 of 3)	35
Figure 1-47	Remove the top cover (3 of 3)	35
Figure 1-48	Remove the front door and front-lower cover (1 of 8)	36
Figure 1-49	Remove the front door and front-lower cover (2 of 8)	37
Figure 1-50	Remove the front door and front-lower cover (3 of 8)	37
Figure 1-51	Remove the front door and front-lower cover (4 of 8)	38
Figure 1-52	Remove the front door and front-lower cover (5 of 8)	38
Figure 1-53	Remove the front door and front-lower cover (6 of 8)	39
Figure 1-54	Remove the front door and front-lower cover (7 of 8)	39
Figure 1-55	Remove the front door and front-lower cover (8 of 8)	40
Figure 1-56	Remove the rear door and rear-lower cover (1 of 5)	41
Figure 1-57	Remove the rear door and rear-lower cover (2 of 5)	41
Figure 1-58	Remove the rear door and rear-lower cover (3 of 5)	42
Figure 1-59	Remove the rear door and rear-lower cover (4 of 5)	42
Figure 1-60	Remove the rear door and rear-lower cover (5 of 5)	43
Figure 1-61	Remove the paper-guide assembly (1 of 2)	44
Figure 1-62	Remove the paper-guide assembly (2 of 2)	44
Figure 1-63	Remove the USB port PCA and bracket (1 of 3)	45
Figure 1-64	Remove the USB port PCA and bracket (2 of 3)	46
Figure 1-65	Remove the USB port PCA and bracket (3 of 3)	46
Figure 1-66	Reinstall the USB port PCA and bracket	47
Figure 1-67	Remove the wireless PCA (1 of 2)	48
Figure 1-68	Remove the wireless PCA (2 of 2)	48
Figure 1-69	Remove the DC controller PCA (1 of 5)	50
Figure 1-70	Remove the DC controller PCA (2 of 5)	50
Figure 1-71	Remove the DC controller PCA (3 of 5)	51
Figure 1-72	Remove the DC controller PCA (4 of 5)	52
Figure 1-73	Remove the DC controller PCA (5 of 5)	52
Figure 1-74	Remove the formatter PCA, fax card PCA, and support bracket (1 of 8)	54
Figure 1-75	Remove the formatter PCA, fax card PCA, and support bracket (2 of 8)	54
Figure 1-76	Remove the formatter PCA, fax card PCA, and support bracket (3 of 8)	55
Figure 1-77	Remove the formatter PCA, fax card PCA, and support bracket (4 of 8)	56
Figure 1-78	Remove the formatter PCA, fax card PCA, and support bracket (5 of 8)	56

xiv ENWW

Figure 1-79	Remove the formatter PCA, fax card PCA, and support bracket (6 of 8)	57
Figure 1-80	Remove the formatter PCA, fax card PCA, and support bracket (7 of 8)	57
Figure 1-81	Remove the formatter PCA, fax card PCA, and support bracket (8 of 8)	58
Figure 1-82	Remove the fuser motor (1 of 2)	
Figure 1-83	Remove the fuser motor (2 of 2)	59
Figure 1-84	Remove the main motor (1 of 4)	60
Figure 1-85	Remove the main motor (2 of 4)	60
Figure 1-86	Remove the main motor (3 of 4)	61
Figure 1-87	Remove the main motor (4 of 4)	61
Figure 1-88	Remove the ITB (1 of 5)	62
Figure 1-89	Remove the ITB (2 of 5)	63
Figure 1-90	Remove the ITB (3 of 5)	63
Figure 1-91	Remove the ITB (4 of 5)	64
Figure 1-92	Remove the ITB (5 of 5)	64
Figure 1-93	Reinstall the ITB (1 of 2)	65
Figure 1-94	Reinstall the ITB (2 of 2)	66
Figure 1-95	Remove the power supply (high-voltage; 1 of 6)	67
Figure 1-96	Remove the power supply (high-voltage; 2 of 6)	68
Figure 1-97	Remove the power supply (high-voltage; 3 of 6)	68
Figure 1-98	Remove the power supply (high-voltage; 4 of 6)	69
Figure 1-99	Remove the power supply (high-voltage; 5 of 6)	69
Figure 1-100	Remove the power supply (high-voltage; 6 of 6)	70
Figure 1-101	Reinstall the power supply (high voltage)	70
Figure 1-102	Remove the power supply (low voltage; 1 of 8)	71
Figure 1-103	Remove the power supply (low voltage; 2 of 8)	72
Figure 1-104	Remove the power supply (low voltage; 3 of 8)	72
Figure 1-105	Remove the power supply (low voltage; 4 of 8)	73
Figure 1-106	Remove the power supply (low voltage; 5 of 8)	73
Figure 1-107	Remove the power supply (low voltage; 6 of 8)	74
Figure 1-108		
Figure 1-109	Remove the power supply (low voltage; 8 of 8)	75
Figure 1-110	Reinstall the power supply (low voltage; 1 of 2)	75
Figure 1-111	Reinstall the power supply (low voltage; 2 of 2)	76
Figure 1-112	Remove the power supply (fuser; 1 of 5)	77
Figure 1-113	Remove the power supply (fuser; 2 of 5)	78
Figure 1-114	Remove the power supply (fuser; 3 of 5)	78
Figure 1-115	Remove the power supply (fuser; 4 of 5)	79
Figure 1-116	Remove the power supply (fuser; 5 of 5)	79
Figure 1-117	Remove the fuser (1 of 4)	80
Figure 1-118	Remove the fuser (2 of 4)	81
Figure 1-119	Remove the fuser (3 of 4)	81
Figure 1-120	Remove the fuser (4 of 4)	82
Figure 1-121	Remove the document feeder separation pad assembly (1 of 7)	83
Figure 1-122	Remove the document feeder separation pad assembly (2 of 7)	83

ENWW

Figure 1-12	3 Remove the document feeder separation pad assembly (3 of 7)	84
Figure 1-12	4 Remove the document feeder separation pad assembly (4 of 7)	84
Figure 1-12	5 Remove the document feeder separation pad assembly (5 of 7)	85
Figure 1-120	6 Remove the document feeder separation pad assembly (6 of 7)	85
Figure 1-12	7 Remove the document feeder separation pad assembly (7 of 7)	86
Figure 1-12	8 Remove the document feeder input tray (1 of 2)	87
Figure 1-12	9 Remove the document feeder input tray (2 of 2)	87
Figure 1-13	0 Remove the document feeder cover (1 of 3)	88
Figure 1-13	1 Remove the document feeder cover (2 of 3)	88
Figure 1-13	2 Remove the document feeder cover (3 of 3)	89
Figure 1-13	3 Remove the document feeder pick arm assembly (1 of 4)	90
Figure 1-13	4 Remove the document feeder pick arm assembly (2 of 4)	90
Figure 1-13	5 Remove the document feeder pick arm assembly (3 of 4)	91
Figure 1-13	6 Remove the document feeder pick arm assembly (4 of 4)	91
Figure 1-13	7 Remove the document feeder core assembly (1 of 3)	92
Figure 1-13	8 Remove the document feeder core assembly (2 of 3)	92
Figure 1-13	9 Remove the document feeder core assembly (3 of 3)	93
Figure 1-140	0 Remove the post scan pinch rollers	94
Figure 1-14	1 Remove the document feeder base assembly (1 of 3)	95
Figure 1-14	2 Remove the document feeder base assembly (2 of 3)	96
Figure 1-14	3 Remove the document feeder base assembly (3 of 3)	96
Figure 1-14	4 Remove the document feeder floating hinges	97
Figure 2-1	DC controller connectors	105
Figure 2-2	Timing diagram	107
Figure 2-3	Circuit diagram	108
Figure 3-1	Base product	161
Figure 3-2	Covers, panels, and doors	162
Figure 3-3	Internal assemblies (1 of 4)	164
Figure 3-4	Internal assemblies (2 of 4)	166
Figure 3-5	Internal assemblies (3 of 4)	168
Figure 3-6	Internal assemblies (4 of 4)	170
Figure 3-7	PCAs	172
Figure 3-8	Scanner and document feeder main assemblies	174
Figure 3-9	Document feeder assembly parts	176

xvi ENWW

1 Removal and replacement

- Introduction
- Removal and replacement strategy
- Electrostatic discharge
- Required tools
- Service approach
- Removal and replacement procedures

ENWW 1

Introduction

This chapter describes the removal and replacement of field-replaceable units (FRUs) only.

Replacing FRUs is generally the reverse of removal. Occasionally, notes and tips are included to provide directions for difficult or critical replacement procedures.

HP does *not* support repairing individual subassemblies or troubleshooting to the component level.

Note the length, diameter, color, type, and location of each screw. Be sure to return each screw to its original location during reassembly.

Incorrectly routed or loose wire harnesses can interfere with other internal components and can become damaged or broken. Frayed or pinched harness wires can be difficult to find. When replacing wire harnesses, always use the provided wire loops, lance points, or wire-harness guides and retainers.

Removal and replacement strategy

▲ WARNING! Turn the product off, wait 5 seconds, and then remove the power cord before attempting to service the product. If this warning is not followed, severe injury can result, in addition to damage to the product. The power must be on for certain functional checks during troubleshooting. However, disconnect the power supply during parts removal.

Never operate or service the product with the protective cover removed from the laser/scanner assembly. The reflected beam, although invisible, can damage your eyes.

The sheet-metal parts can have sharp edges. Be careful when handling sheet-metal parts.

- △ CAUTION: Do not bend or fold the flat flexible cables (FFCs) during removal or installation. Also, do not straighten pre-folds in the FFCs. You *must* fully seat all FFCs in their connectors. Failure to fully seat an FFC into a connector can cause a short circuit in a PCA.
- NOTE: To install a self-tapping screw, first turn it counterclockwise to align it with the existing thread pattern, and then carefully turn it clockwise to tighten. Do not overtighten. If a self-tapping screw-hole becomes stripped, repair the screw-hole or replace the affected assembly.
- TIP: For clarity, some photos in this chapter might show components removed that would not be removed to service the product. If necessary, remove the components listed at the beginning of a procedure before proceeding to service the product.

Some components require inspection, cleaning, or replacement when a product is serviced. Use the table below to identify these components, and determine if any service related action is necessary.

Table 1-1 Components inspection

Component	If the product has printed less than 10,000 pages	If the product has printed more than 10,000 pages			
Pickup roller (product base)	Inspect	If this component is damaged, discard the product.			
	 Clean 	the product.			
	Replace if damaged				

Table 1-1 Components inspection (continued)

Component	If the product has printed less than 10,000 pages	If the product has printed more than 10,000 pages			
Separation roller (product base)	 Inspect 	If this component is damaged, discard			
	• Clean	the product.			
	Replace if damaged				
Document feeder pick arm assembly (includes the pickup rollers)	 Inspect 	If this component is damaged, discard			
	• Clean	the product.			
	Replace if damaged				
Document feeder separation pad	If the product has printed less than 15,000 pages	If the product has printed more than 15,000 pages, discard the product.			
	Inspect				
	• Clean				
	Replace if damaged				
Intermediate transfer belt (ITB)	Inspect	If this component is damaged, discard the product.			
	• Clean	the product.			
	Replace if damaged				
Transfer roller	Inspect	If this component is damaged, discard the product.			
	• Clean				
	Replace if damaged				
Fuser	Inspect	If this component is damaged, discard the product.			
	• Clean				
	Replace if damaged				
Covers	 Inspect 	If this component is damaged, discard			
	• Clean	the product.			
	Replace if damaged				

Electrostatic discharge

△ CAUTION: Some parts

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Look for the ESD reminder when removing product parts. Always perform service work at an ESD-protected workstation or mat, or use an ESD strap. If an ESD workstation, mat, or strap is not available, ground yourself by touching the sheet-metal chassis *before* touching an ESD-sensitive part.


Protect the ESD-sensitive parts by placing them in ESD pouches when they are out of the product.

Required tools

- #2 Phillips screwdriver with a magnetic tip and a 152-mm (6-in) shaft length
- Small flat-blade screwdriver
- Torx driver (#10)
- Needle-nose pliers
- ESD mat or ESD strap (if one is available)
- Penlight (optional)

△ CAUTION: Always use a Phillips screwdriver (callout 1). Do not use a Pozidrive screwdriver (callout 2) or any motorized screwdriver. These can damage screws or screw threads.

Figure 1-1 Phillips and Pozidrive screwdriver comparison




Service approach

Before performing service

- Remove all paper from the product.
- Turn off the power using the power switch.
- Unplug the power cable and interface cable or cables.
- Place the product on an ESD workstation or mat, or use an ESD strap (if one is available). If an ESD workstation, mat, or strap is not available, ground yourself by touching the sheet-metal chassis before touching an ESD-sensitive part.
- Remove the print cartridges.
- △ CAUTION: Do not touch the imaging drum on the bottom of the print cartridge. Finger prints on the imaging drum can cause print-quality problems.

Do not allow the image drum to contact any surface when the cartridges are set down. Protect the image drum at all times. Dust and debris can stick to the drum and cause print-quality problems.



ENWW Service approach

After performing service

- Plug in the interface cables, and then the power cable.
- Reinstall the print cartridges.
- Load paper in the product.

Post-service tests

After service has been completed, perform the following tests to verify that the repair or replacement was successful.

Test 1 (print-quality test)

- 1. Verify that you have completed the necessary reassembly steps.
- 2. Ensure that the input tray contains clean, unmarked paper.
- 3. With the power cord and interface cables attached, turn on the product.
- Verify that the expected start up sounds occur.
- 5. Print a configuration page, and then verify that the expected printing sounds occur.
- 6. Print a demo page, and then verify that the print quality is as expected.
- 7. Send a print job from the host computer, and then verify that the output meets expectations.
- 8. If necessary, restore any customer-specified settings.
- 9. Clean the outside of the product with a damp cloth.

Test 2 (copy-quality test)

- 1. Verify that you have completed the necessary reassembly steps.
- 2. Ensure that the input tray contains clean, unmarked paper.
- 3. With the power cord attached, turn on the product.
- 4. Verify that the expected start up sounds occur.
- 5. Print a configuration page, and then verify that the expected printing sounds occur.
- 6. Place the configuration page in the document feeder, or on the flatbed glass.
- 7. Print a copy job, and then verify the results.
- 8. Clean the outside of the product with a damp cloth.

Test 3 (fax-quality test)

- 1. Place the configuration page in the document feeder.
- 2. Type a valid fax number and send the fax job.
- 3. Verify that the send quality and receive quality meet expectations.

Parts removal order

Use the following diagram to determine which parts must be removed before removing other parts.

Figure 1-2 Parts-removal tree

Component	Remove	Remove	Remove	Remove	Remove	Remove	Remove	Remove	Remove	Remove
Pickup roller										
Separation roller										
Transfer roller										
Print cartridge drawer										
Right cover										
Right-front cover1 and cover 2	Right cover									
Control panel	Right cover	Right-front cover 1/2								
Left cover										
Document-feeder and scanner assembly	Right cover									
Rear-center cover	Right cover									
Rear-upper cover	Right cover	Left cover	Rear-center cover							
Speaker	Right cover	Control panel								
Top cover	Right cover	Right-front cover1/2	Control panel	Left cover	Document-feeder	Rear-center cover	Rear-upper cover	Speaker		
Front door	Print cartridge	Left cover			and scanner assembly					
and front-lower cover	drawer									
Rear door and rear-lower cover	Right cover	Left cover	Rear-center cover							
Paper guide assembly										
USB port PCA and bracket	Right cover	Right-front cover1/2								
Wireless PCA	Right cover	.								
DC controller PCA	Right cover									
Formatter PCA, fax card PCA and support bracket	Right cover									
Fuser motor	Right cover	Formatter PCA, fax card	PCA and support b	racket						
	at I.			1.						
Main motor	Right cover	Formatter PCA, fax card								
Intermediate transfer belt (ITB)	Print cartridge drawer	Right cover	Left cover	Rear-center cover						
Power supply (high voltage)	Right cover	Right-front cover1/2	Control panel	Left cover	Document-feeder and scanner assembly	Rear-center cover	Rear-upper cover	Speaker	Top cover	
Power supply (low voltage)	Right cover	Left cover	Rear-center cover	Rear door and rear-lower cover	Formatter PCA, fax card and support bracket	I PCA				
Power supply (fuser)	Right cover	Left cover	Rear-center cover	Rear door and rear-lower cover						
Fuser	Right cover	Right-front cover1/2	Control panel	Left cover	Document-feeder and scanner assembly	Rear-center cover	Rear-upper cover	Speaker	Top cover	Rear door and rear-lower cover
Document feeder input tray					·					
Document feeder cover	D	Document feeder cover								
Document feeder pick arm assembly	Document feeder input tray									
Document feeder core	Document feeder input tray	Document feeder cover								
Document feeder pinch rollers	Document feeder input tray	Document feeder cover	Document feeder core							
Document feeder base assembly	Document feeder input tray	Document feeder cover	Document feeder core							
Document feeder floating hinges	Document feeder input tray	Document feeder cover	Document feeder core	Document feeder assembly	base					

ENWW Service approach 7

Removal and replacement procedures

Pickup roller

You might have to rotate the pickup roller to gain access to the roller locking tabs.

Remove the input tray and tilt the product back until the pickup roller is visible.

If the locking tabs on each side of the roller are not accessible, use the following procedure in this step to rotate the roller and access the tabs.

If the tabs are visible, proceed to the next step.


- **a.** Reinstall the input tray, and then turn the product on.
- **b.** Touch the Setup \(\) button.
- **c.** Touch the middle of the screen along the left-hand edge (callout 1), and then immediately touch the lower-right corner (callout 2) of the screen.



- **d.** When the Home screen appears, touch the Setup \(\) button again.
- e. Touch the 2ndary Service button.
- **f.** Touch the arrow buttons (at the right- or left-side of the touch screen) until the Pick roller button appears.
- g. Touch the Pick roller button.
- **h.** Touch the OK button to confirm that you want the pick roller to rotate.
- i. Turn the product power off, and then remove the power cord and the interface cable.
- Carefully place the product front-side up.
 - △ CAUTION: The document-feeder and scanner cover are not captive and can open suddenly if the product is placed front-side up. Always support the document-feeder and scanner cover before placing the product front-side up.
- NOTE: Debris can scratch or damage the back of the product. Before you place the product front-side up, remove any debris from the work surface. If possible, set the product on a clean, dry cloth to prevent scratching and damage.

- 3. Release two white plastic locking tabs and remove the pickup roller.
- △ CAUTION: Do not touch the spongy roller surface unless you are going to replace the roller. Skin oils on the roller can cause paper pickup problems.

Figure 1-3 Remove the pickup roller



Separation roller

- △ CAUTION: Do not touch the spongy roller surface unless you are going to replace the roller. Skin oils on the roller can cause paper pickup problems.
 - 1. Remove paper tray (if installed), and then carefully place the product front-side up.
 - △ CAUTION: The document-feeder and scanner cover are not captive and can open suddenly if the product is placed front-side up. Always support the document-feeder and scanner cover before placing the product front-side up.
 - NOTE: Debris can scratch or damage the back of the product. Before you place the product front-side up, remove any debris from the work surface. If possible, set the product on a clean, dry cloth to prevent scratching and damage.
 - Carefully release the roller cover and rotate it down and away from the roller.
 - Reinstallation tip Make sure that this cover snaps into place over the roller when the roller and holder are reinstalled.






Figure 1-4 Remove the separation roller (1 of 2)

Use a small flat blade screwdriver to gently pry up on the roller and holder assembly (callout 1) to remove the roller and holder assembly.






Transfer roller


- 1. Open the rear door.
- Release the retainer clip and then rotate it until the pin on the clip aligns with the slot in the mounting bracket.

Figure 1-6 Remove the transfer roller (1 of 3)



- 3. Remove the clip. Repeat these steps for the remaining retainer clip (located at the opposite end of the roller shaft).
- TIP: One of the clips (callout 1) is made from a black conductive plastic. Make sure that the clips are reinstalled on correct the end of the transfer roller.

Figure 1-7 Remove the transfer roller (2 of 3)



- Slide the roller to one side to disengage the roller shaft from the mounting bracket, and then remove the transfer roller.
- △ CAUTION: Do not touch the black sponge portion of the roller. Skin oils can cause print-quality problems.

Figure 1-8 Remove the transfer roller (3 of 3)



Print-cartridge drawer

1. Open the front door and pull out the print-cartridge drawer.






2. Use a small flat blade screwdriver to release one tab (callout 1) on the cartridge-drawer stop.

Figure 1-10 Remove the print-cartridge drawer (2 of 5)



3. Push in on the edge of the top cover (callout 1), rotate the end of the drawer stop toward the center of the print-cartridge drawer (callout 2), and then remove the drawer stop (callout 3)





4. Repeat the previous steps to remove the remaining drawer stop.






5. Pull the print-cartridge drawer out of the product to remove it.


Figure 1-13 Remove the print-cartridge drawer (5 of 5)



Right cover


1. Before proceeding, note the locations of the retaining clips on the back of the cover.






2. Remove one screw (callout 1).

Figure 1-15 Remove the right cover (2 of 5)




3. Release two tabs (callout 1), and then slightly separate the back side of the cover from the product.





4. Pull down on the bottom-front corner of the cover, and then slightly rotate the bottom of the cover away from the product.

Figure 1-17 Remove the right cover (4 of 5)




5. Slide the cover toward the back of the product to remove it.


Figure 1-18 Remove the right cover (5 of 5)




Right-front cover-1 and cover-2


- 1. Remove the right cover. See Right cover on page 17.
- 2. Remove two screws (callout 1), and then remove the right-front cover-2 (callout 2)





3. Open the front door, and then use a small flat blade screwdriver to release one tab (callout 1).






4. Rotate the top of the right-front cover-1 away from the product, and then lift the cover up to release it.

Figure 1-21 Remove the right-front cover (3 of 4)




5. Remove the right-front cover-1.


Figure 1-22 Remove the right-front cover (4 of 4)



Control panel


- 1. Remove the following components:
 - Right cover. See <u>Right cover on page 17</u>.
 - Right-front cover-1 and cover-2. See Right-front cover-1 and cover-2 on page 20.
- 2. Remove one locator screw (callout 1), and then remove the ESD bracket screw (callout 2) and the mounting screw (callout 3).
- NOTE: When the control panel is reinstalled, install the locator screw (callout 1) first to correctly position the control panel on the product. Install the ESD bracket screw (callout 2) and the mounting screw (callout 3) after the locator screw is tightened.







- 3. Slightly slide the control panel toward the front of the product, and then lift it off of the product.
 - △ CAUTION: The control panel is still attached to the product by the FFCs. Do not damage the FFCs when you separate the control panel from the product.

Figure 1-24 Remove the control panel (2 of 5)





4. Disconnect two FFCs (callout 1) from the bottom of the control-panel PCA.







- 5. Turn the control panel over, and then remove five screws (callout 1) and the ESD bracket (callout 2).
- NOTE: Install the ESD bracket on the replacement control-panel PCA assembly.






6. Separate the control-panel base (callout 1) from the control-panel PCA assembly (callout 2).






Left cover


1. Before proceeding, note of the locations of the retaining tabs on the back of the left cover.






2. Remove one screw (callout 1).

Figure 1-29 Remove the left cover (2 of 6)




3. Release one tab (callout 1).

Figure 1-30 Remove the left cover (3 of 6)



4. Push in on the back side of the cover to release one tab (callout 1), and rotate the back edge of the cover away from the product.

Figure 1-31 Remove the left cover (4 of 6)



5. Open the front door, and then use a small flat blade screwdriver to release two tabs (callout 1)

Figure 1-32 Remove the left cover (5 of 6)



6. Rotate the cover toward the front of the product, and then remove the cover.


Figure 1-33 Remove the left cover (6 of 6)



Document-feeder and scanner assembly


- 1. Remove the right cover. See Right cover on page 17.
- 2. Disconnect two FFCs (callout 1).

Figure 1-34 Remove the document-feeder and scanner assembly (1 of 3)



3. Remove four screws (callout 1).

Figure 1-35 Remove the document-feeder and scanner assembly (2 of 3)



 Slightly slide the document-feeder and scanner assembly toward the rear of the product, and then lift it straight up and off of the product.







Rear-center cover


- 1. Remove the right cover. See Right cover on page 17.
- 2. Open the rear door.
- Use a small flat blade screwdriver to release one tab (callout 1), and then slightly separate the top of the cover from the product.

Figure 1-37 Remove the rear-center cover (1 of 2)



4. Release one tab (callout 1), and then remove the rear-center cover (callout 2).






Rear-upper cover


- 1. Remove the following components:
 - Right cover. See <u>Right cover on page 17</u>.
 - Left cover. See <u>Left cover on page 25</u>.
 - Rear-center cover. See <u>Rear-center cover on page 30</u>.
- Remove four screws (callout 1).

Figure 1-39 Remove the rear-upper cover (1 of 4)





- 3. Slightly separate the scanner assembly from the product base.
 - \triangle **CAUTION:** The scanner assembly is still connected to the product base by two FFCs. Separate the assembly from the base only enough to remove the cover.

Figure 1-40 Remove the rear-upper cover (2 of 4)



4. Open the rear door. Use a small flat blade screwdriver to push down on two tabs (callout 1) to release them.





5. Rotate the bottom of the rear-upper cover away from the product to remove it.


Figure 1-42 Remove the rear-upper cover (4 of 4)



Speaker


- 1. Remove the following components:
 - Right cover. See <u>Right cover on page 17</u>.
 - Right-front cover-1 and cover-2. See Right-front cover-1 and cover-2 on page 20.
 - Control panel. See <u>Control panel on page 22</u>.
- 2. Disconnect one wire-harness connector (callout 1), and then release the wire harness from the retainers (callout 2).

Figure 1-43 Remove the speaker (1 of 2)




3. Disconnect one wire-harness connector (callout 1), and then release the wire harness from the retainers (callout 2).


Figure 1-44 Remove the speaker (2 of 2)



Top cover


- 1. Remove the following components:
 - Right cover. See <u>Right cover on page 17</u>.
 - Right-front cover-1 and cover-2. See Right-front cover-1 and cover-2 on page 20.
 - Control panel. See <u>Control panel on page 22</u>.
 - Left cover. See Left cover on page 25.
 - Document-feeder and scanner assembly. See <u>Document-feeder and scanner assembly</u> on page 28.
 - Rear-center cover. See <u>Rear-center cover on page 30</u>.
 - Rear-upper cover. See Rear-upper cover on page 31.
 - Speaker on page 33.
- 2. Wireless models only: Disconnect one wire-harness connector (callout 1), remove one screw (callout 2), and then remove the wireless PCA (callout 3).






3. Remove seven screws (callout 1).

Figure 1-46 Remove the top cover (2 of 3)




4. Remove the top cover.

Figure 1-47 Remove the top cover (3 of 3)




Front door and front-lower cover

- 1. Remove the following components:
 - Print-cartridge drawer. See Print-cartridge drawer on page 14.
 - Left cover. See Left cover on page 25.
- 2. Remove the paper tray (if installed), and then carefully place the product front-side up
 - △ CAUTION: The document-feeder and scanner cover are not captive and can open suddenly if the product is placed front-side up. Always support the document-feeder and scanner cover before placing the product front-side up.
- 3. Release three tabs (callout 1) and then push the guide into the product (away from the input-tray cavity).




4. Remove the guide.

Figure 1-49 Remove the front door and front-lower cover (2 of 8)




5. Carefully push the right-side front-lower door hinge in toward the center of the door to release it from the hinge pin.

Figure 1-50 Remove the front door and front-lower cover (3 of 8)





6. Slide the door to the right to release the left-side hinge. Remove the front-lower door.





7. Use a small flat blade screwdriver to release one retainer pin (callout 1) on the left-side front-door cam. Remove the retainer pin.






- 8. Repeat the previous step for the right-side retainer pin.
 - Reinstallation tip The door pins are keyed to the door cam. The pins must be correctly positioned when they are reinstalled or they will not completely seat in the door cam.

Figure 1-53 Remove the front door and front-lower cover (6 of 8)





- 9. Release one tab (callout 1), rotate the door retainer clip up and away from the door, and then remove the clip.
- NOTE: Support the door when this clip is removed.

Figure 1-54 Remove the front door and front-lower cover (7 of 8)



10. Lower the left side of the door, and then slide it to the left to release the right-side door hinge pin. Remove the door.







Rear door and rear-lower cover


- 1. Remove the following components:
 - Right cover. See <u>Right cover on page 17</u>.
 - Left cover. See <u>Left cover on page 25</u>.
 - Rear-center cover. See <u>Rear-center cover on page 30</u>.
- 2. Remove two screws (callout 1)

Figure 1-56 Remove the rear door and rear-lower cover (1 of 5)




3. Release one pin (callout 1) and then slide the rear door and rear-lower cover towards the side of the product with the interface connectors.






4. Remove the rear door and rear-lower cover.

Figure 1-58 Remove the rear door and rear-lower cover (3 of 5)




5. Carefully pry the rear-door hinge arms off of the hinge pins (callout 1) on the rear-lower cover to separate the rear cover from the rear door.

Figure 1-59 Remove the rear door and rear-lower cover (4 of 5)



- Separate the rear cover from the rear door.
- NOTE: If you are installing a replacement rear-lower door, remove the paper-guide assembly from the discarded door, and then install it on the replacement door. See Paper-guide assembly on page 44.

Figure 1-60 Remove the rear door and rear-lower cover (5 of 5)





Main assemblies

NOTE: The laser scanner installed in this product is not replaceable.


Paper-guide assembly


1. Release one captive screw (callout 1) and release two tabs (callout 2).





2. Rotate the assembly up and away from the rear door to release it, and then remove the paperguide assembly





USB port PCA and bracket

- NOTE: To replace only the USB port PCA, you do not need to remove the sheet-metal bracket. Remove the two screws securing the PCA to the bracket, and then disconnect one wire-harness connector.
 - Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, ground yourself by touching the sheet-metal chassis *before* touching an ESD-sensitive part.
 - Remove the following components:
 - Right cover. See <u>Right cover on page 17</u>.
 - Right-front cover-1 and cover-2. See <u>Right-front cover-1 and cover-2 on page 20</u>.
 - Remove two screws (callout 1), and then remove the USB port and sheet-metal mounting bracket.
 - △ CAUTION: The USB port PCA is still connected to the product by the wire harness.





Figure 1-63 Remove the USB port PCA and bracket (1 of 3)


3. Disconnect one wire-harness connector (callout 1).

Figure 1-64 Remove the USB port PCA and bracket (2 of 3)



4. Remove two screws (callout 1), and then separate the USB port PCA (callout 2) from the mounting bracket (callout 3) to remove it.


Figure 1-65 Remove the USB port PCA and bracket (3 of 3)



Reinstall the USB port PCA

When the USB port PCA and mounting bracket are reinstalled, make sure that the cable is routed behind the cable retainers (callout 1)






Wireless PCA (wireless models only)


- CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, ground yourself by touching the sheet-metal chassis *before* touching an ESD-sensitive part.
 - 1. Remove the right cover. See Right cover on page 17.
 - Disconnect one wire-harness connector, and then remove one screw (callout 2).

Figure 1-67 Remove the wireless PCA (1 of 2)



3. Remove the wireless PCA.

Figure 1-68 Remove the wireless PCA (2 of 2)



DC controller PCA

Special considerations

△ WARNING! Do not install a *replacement* formatter PCA and DC controller PCA at the same time.

The formatter PCA and the DC controller PCA store important product configuration information (NVRAM data) that will be lost if both PCAs are replaced at the same time. When the product power is turned on, the formatter will restore the NVRAM data to a replacement DC controller.

Replacing both the DC controller and the formatter at the same time will result in severe print-quality problems.

Replacing the DC controller PCA before the formatter PCA

Use the following procedure if you need to install a replacement DC controller *and* a replacement formatter PCA.


- NOTE: If you are only installing a replacement DC controller PCA, proceed to Remove the DC controller PCA on page 49.
 - 1. Install a replacement DC controller PCA.
 - 2. Turn the product power on, and wait for the print-cartridge volume indicators to appear on the control-panel display.
 - NOTE: This allows important product information to be written to the replacement DC controller PCA.
 - Turn the product power off.
 - Install a replacement formatter PCA. See <u>Formatter PCA</u>, fax card <u>PCA</u>, and <u>support bracket</u> on page 53.
 - Turn the product power on.

Remove the DC controller PCA

- △ CAUTION: Do not bend or fold the flat flexible cables (FFCs) during removal or installation. Also, do not straighten pre-folds in the FFCs. You *must* make sure that all FFCs are fully seated in their connectors. Failure to fully seat an FFC into a connector can cause a short circuit in a PCA.
 - Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, ground yourself by touching the sheet-metal chassis *before* touching an ESD-sensitive part.
 - 1. Remove the right cover. See Right cover on page 17.


- 2. Release one tab (callout 1) on the black-plastic protective cover.
- NOTE: This cover is located near the lower-right side of the product below the DC controller.






3. Remove the cover.

Figure 1-70 Remove the DC controller PCA (2 of 5)



Disconnect fifteen wire-harness connectors and three FFCs from the DC controller PCA.


Figure 1-71 Remove the DC controller PCA (3 of 5)



Item	Description	Item	Description	Item	Description
1	J102	7	J109	13	J116
	Low-voltage power supply (+24 v)		Scanner motor		Pickup assembly sensors
2	J103	8	J110	14	J118
	Low-voltage power supply (+3.3 v)		Fuser motor		Media width sensor
3	J104	9	J111	15	J119
	Fuser thermistor		Pickup assembly motor		ITB assembly sensors
4	J105	10	J112	16	J120
	Fuser power		Developing disengagement solenoid		Developing home position sensor
5	J107	11	J113	17	J121
	Formatter		Pickup solenoid		Main motor
6	J108	12	J115	18	J124
	Laser		High-voltage power supply		E-label


- 5. Remove four screws (callout 1).
- NOTE: These four screws are ground screws. Make sure that the correct screws are used to reinstall the DC controller PCA.

Figure 1-72 Remove the DC controller PCA (4 of 5)



6. Remove the DC controller PCA.

Figure 1-73 Remove the DC controller PCA (5 of 5)



Formatter PCA, fax card PCA, and support bracket

Special considerations

<u>MARNING!</u> Do not install a *replacement* formatter PCA and DC controller PCA at the same time.

The formatter PCA and the DC controller PCA store important product configuration information (NVRAM data) that will be lost if both PCAs are replaced at the same time. When the product power is turned on, the DC controller will restore the NVRAM data on the replacement formatter.

Replacing both the formatter and the DC controller at the same time will result in severe print-quality problems.

NOTE: The base model does not have a fax card installed.

Replacing the formatter PCA before the DC controller PCA


Use the following procedure if you need to install a replacement formatter PCA and a replacement DC controller.


- NOTE: If you are only installing a replacement formatter PCA, proceed to Remove the formatter PCA on page 53.
 - 1. Install a replacement formatter PCA.
 - 2. Turn the product power on, and wait for the print-cartridge volume indicators to appear on the control-panel display.
 - NOTE: This allows important product information to be written to the replacement formatter PCA.
 - Turn the product power off.
 - 4. Install a replacement DC controller. See <u>DC controller PCA on page 49</u>.
 - 5. Turn the product power on.

Remove the formatter PCA

- △ CAUTION: Do not bend or fold the flat flexible cables (FFCs) during removal or installation. Also, do not straighten pre-folds in the FFCs. You *must* make sure that all FFCs are fully seated in their connectors. Failure to fully seat an FFC into a connector can cause a short circuit in a PCA.
 - Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, ground yourself by touching the sheet-metal chassis *before* touching an ESD-sensitive part.
 - 1. Remove the right cover. See Right cover on page 17.


2. Disconnect one connector (callout 1), and remove four screws (callout 2).






3. Remove the Fax PCA.

Figure 1-75 Remove the formatter PCA, fax card PCA, and support bracket (2 of 8)



Disconnect six wire-harness connectors and four FFCs on the formatter PCA.


Figure 1-76 Remove the formatter PCA, fax card PCA, and support bracket (3 of 8)



Item	Description	Item	Description
1	J1	6	J18
	Wireless PCA (wireless models only)		Document feeder motor (ADF)
2	J8	7	J19
	Speaker		USB PCA (thumb drive)
3	J10	8	J23
	Power (LVPS)		Control panel
4	J13	9	J24
	Fax PCA		Control panel
5	J17	10	J31
	Scanner		Video


5. Remove six screws (callout 1).

Figure 1-77 Remove the formatter PCA, fax card PCA, and support bracket (4 of 8)




6. Remove the formatter PCA.

Figure 1-78 Remove the formatter PCA, fax card PCA, and support bracket (5 of 8)




- Remove one FFC (callout 1) from the support bracket. Disconnect one FFC (callout 2) from the DC controller.
- △ CAUTION: One FFC (callout 2) is fastened to the support bracket with insulating adhesive foam tape. If you are replacing the support bracket, you will need to adhere this FFC to the replacement bracket with the same type of material. This FFC must be shielded from direct contact with the support bracket.

Figure 1-79 Remove the formatter PCA, fax card PCA, and support bracket (6 of 8)




8. Remove six screws (callout 1).

Figure 1-80 Remove the formatter PCA, fax card PCA, and support bracket (7 of 8)



9. Remove the support bracket.


Figure 1-81 Remove the formatter PCA, fax card PCA, and support bracket (8 of 8)




Fuser motor


- 1. Remove the following components:
 - Right cover. See <u>Right cover on page 17</u>.
 - Formatter PCA, fax PCA, and support bracket. See <u>Formatter PCA</u>, fax card PCA, and <u>support bracket on page 53</u>.
- 2. Disconnect one wire-harness connector (callout 1), and then remove two screws (callout 2).

Figure 1-82 Remove the fuser motor (1 of 2)



3. Slightly slide the motor up so that the gear on the motor shaft is centered in the mounting bracket hole, and then pull the motor away from the product. The gear will pass through the large hole in the bracket.







Main motor


- 1. Remove the following components:
 - Right cover. See <u>Right cover on page 17</u>.
 - Formatter PCA, fax PCA, and support bracket. See <u>Formatter PCA</u>, fax card <u>PCA</u>, and <u>support bracket on page 53</u>.
- 2. Disconnect one wire-harness connector (callout 1), and then release the wire harness from the retainer (callout 2).

Figure 1-84 Remove the main motor (1 of 4)




3. Release two tabs (callout 1), and then pull down on the black-plastic wire-harness retainer to release it.






Remove the wire retainer.

Figure 1-86 Remove the main motor (3 of 4)




Remove four screws (callout 1) and then remove the main motor.


Figure 1-87 Remove the main motor (4 of 4)



Intermediate transfer belt (ITB)


- 1. Remove the following components:
 - Print-cartridge drawer. See Print-cartridge drawer on page 14.
 - Right cover. See Right cover on page 17.
 - Left cover. See <u>Left cover on page 25</u>.
 - Rear-center cover. See Rear-center cover on page 30.
- 2. Disconnect one wire-harness connector (callout 1), and then release the wire harness from the retainer (callout 2).





3. Open the rear door, and then remove one screw (callout 1), and then remove the print-cartridge drawer stop (callout 2).

Figure 1-89 Remove the ITB (2 of 5)




- 4. Carefully lift up on the black plastic portion of the ITB, and then pull it *partially* out of the product (the ITB wire harness will prevent the ITB from being fully removed).

See <u>Figure 1-92 Remove the ITB (5 of 5) on page 64</u> to see how to correctly handle the ITB to prevent damaging it. Do not lift the ITB by grasping the sheet-metal bracket.


△ CAUTION: Avoid touching the black plastic transfer belt. Skin oils on the belt might cause print-quality problems.

Figure 1-90 Remove the ITB (3 of 5)




5. Feed the ITB wire harness (callout 1) through an opening in the chassis (callout 2).

Figure 1-91 Remove the ITB (4 of 5)



- 6. Carefully pull the ITB straight out of the product.
- △ CAUTION: Make sure that the ITB wire harness does not get damaged as the ITB is removed from the chassis.

Figure 1-92 Remove the ITB (5 of 5)




Reinstall the ITB

Use the following guidelines when you install the ITB.

• <u>MARNING!</u> The lower sheet-metal portion of the ITB frame (callout 1) can be easily bent. Avoid handling the ITB by this part of the sheet-metal frame.

Figure 1-93 Reinstall the ITB (1 of 2)



- When handling the ITB, always use the hard plastic portions of the assembly.
- △ CAUTION: Avoid touching the black-plastic transfer belt or roller. Skin oils on the belt or roller might cause print-quality problems.
- Do not let the transfer belt contact hard or sharp objects.
- △ CAUTION: Scratches, punctures, or other damage to the belt will cause print-quality problems.
- Make sure that the wire harness is not twisted or pinched after it is passed through the opening
 in the chassis, and that the ITB sits flat in the product.
- NOTE: When the print-cartridge drawer is installed, it should easily slide in and out of the product and not contact any part of the ITB assembly.

• Tape the wire harness to the sheet-metal frame so that it will not catch on internal components as the ITB is installed.


With the ITB partially installed, feed the wire harness through the opening in the chassis. See <u>Figure 1-91 Remove the ITB (4 of 5) on page 64</u>. Finish installing the ITB.

▲ WARNING! Do not place the tape so that it makes contact or adheres to the transfer belt. Tape or tape residue on the transfer belt will cause print-quality problems.

Make sure that the ITB is fully seated in the product before you reinstall the print-cartridge door stop.

NOTE: Make sure that you remove all of the tape and tape residue after installing the ITB.







Power supply (high-voltage)


- △ CAUTION: Do not bend or fold the flat flexible cables (FFCs) during removal or installation. Also, do not straighten pre-folds in the FFCs. You *must* make sure that all FFCs are fully seated in their connectors. Failure to fully seat an FFC into a connector can cause a short circuit in a PCA.
 - Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, ground yourself by touching the sheet-metal chassis *before* touching an ESD-sensitive part.
 - Remove the following components:
 - Right cover. See <u>Right cover on page 17</u>.
 - Right-front cover-1 and cover-2. See <u>Right-front cover-1 and cover-2 on page 20</u>.
 - Control panel. See <u>Control panel on page 22</u>.
 - Left cover. See <u>Left cover on page 25</u>.
 - Document-feeder and scanner assembly. See <u>Document-feeder and scanner assembly</u> on page 28.
 - Rear-center cover. See Rear-center cover on page 30.
 - Rear-upper cover. See Rear-upper cover on page 31.
 - Speaker. See <u>Speaker on page 33</u>
 - Top cover. See <u>Top cover on page 34</u>.
 - 2. Disconnect one FFC (callout 1).
 - NOTE: This FFC connects the DC controller (shown below) to the high-voltage power supply.

Figure 1-95 Remove the power supply (high-voltage; 1 of 6)




3. Disconnect two wire-harness connectors (callout 1) and release the wire harness from the retainer (callout 2).






4. Remove one screw (callout 1) and then release the sub-PCA from the chassis (callout 2).

Figure 1-97 Remove the power supply (high-voltage; 3 of 6)




Remove four screws (callout 6).

Figure 1-98 Remove the power supply (high-voltage; 4 of 6)




Release seven tabs (callout 8).

Figure 1-99 Remove the power supply (high-voltage; 5 of 6)




7. Remove the power supply.


Figure 1-100 Remove the power supply (high-voltage; 6 of 6)



Reinstall the power supply (high voltage)

Make sure that the power supply is correctly positioned under the tabs (callout 1) located on the
product chassis. If the power supply is not correctly installed, the product will not function
correctly and a fuser open error (50.7000) might appear in the event log.





Power supply (low voltage)

△ CAUTION: Do not bend or fold the flat flexible cables (FFCs) during removal or installation. Also, do not straighten pre-folds in the FFCs. You *must* make sure that all FFCs are fully seated in their connectors. Failure to fully seat an FFC into a connector can cause a short circuit in a PCA.

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, ground yourself by touching the sheet-metal chassis *before* touching an ESD-sensitive part.

- Remove the following components:
 - Right cover. See Right cover on page 17.
 - Left cover. See <u>Left cover on page 25</u>.
 - Rear-center cover. See Rear-center cover on page 30.
 - Rear door and rear-lower cover. See Rear door and rear-lower cover on page 41.
 - Formatter PCA, fax PCA, and support bracket. See Formatter PCA, fax card PCA, and support bracket on page 53.
- 2. Remove two screws (callout 1) and the black-plastic cover (callout 2).





Figure 1-102 Remove the power supply (low voltage; 1 of 8)


3. Disconnect one wire-harness connector (callout 1) and release the wire harness from the retainer (callout 2).






- 4. Release one tab (callout 1) on the black-plastic protective cover.
- NOTE: This cover is located near the lower-right side of the product below the DC controller.

Figure 1-104 Remove the power supply (low voltage; 3 of 8)




5. Remove the cover.

Figure 1-105 Remove the power supply (low voltage; 4 of 8)




6. Disconnect two wire-harness connectors (callout 1), and then release the wire harnesses from the retainer (callout 2).

Figure 1-106 Remove the power supply (low voltage; 5 of 8)




7. Release two tabs (callout 1), and then pull the black-plastic cover away from the product to remove it.






8. Remove two screws (callout 1).

Figure 1-108 Remove the power supply (low voltage; 7 of 8)



- 9. Rotate the end of the power supply near the front of the product out and away from the product (callout 1) until it clears the chassis, and then slide the power supply toward the front of the product to remove it (callout 2).
 - NOTE: As you remove the power supply, feed the wire harness at the rear of the product through the opening in the chassis (callout 3).







Reinstall the power supply (low voltage)


1. Make sure that the hook on the power supply tray is correctly engaged with the slot at the back side of the product chassis.

Figure 1-110 Reinstall the power supply (low voltage; 1 of 2)



Make sure that the power supply tray is correctly engaged with the mounting rail near the front of the product chassis.







Power supply (fuser)


- CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, ground yourself by touching the sheet-metal chassis *before* touching an ESD-sensitive part.
 - 1. Remove the following components:
 - Right cover. See Right cover on page 17.
 - Left cover. See <u>Left cover on page 25</u>.
 - Rear-center cover. See Rear-center cover on page 30.
 - Rear door and rear-lower cover. See Rear door and rear-lower cover on page 41.
 - 2. Remove two screws (callout 1) and the black-plastic cover (callout 2).

Figure 1-112 Remove the power supply (fuser; 1 of 5)




3. Disconnect three wire-harness connectors (callout 1), and then remove the wire harness from the retainer (callout 2).






4. Release one tab (callout 1), slide the retainer toward the formatter side of the product to release it, and then remove the retainer from the chassis.

Figure 1-114 Remove the power supply (fuser; 3 of 5)



- Remove four screws (callout 1).
- NOTE: The two screws near the power switch are ground screws. Make sure that these screws are placed in the correct positions when the power supply is reinstalled.

Figure 1-115 Remove the power supply (fuser; 4 of 5)




Remove the power supply.


Figure 1-116 Remove the power supply (fuser; 5 of 5)



Fuser


- Remove the following components:
 - Right cover. See Right cover on page 17.
 - Right-front cover-1 and cover-2. See Right-front cover-1 and cover-2 on page 20.
 - Control panel. See Control panel on page 22.
 - Left cover. See Left cover on page 25.
 - Document-feeder and scanner assembly. See <u>Document-feeder and scanner assembly</u> on page 28.
 - Rear-center cover. See Rear-center cover on page 30.
 - Rear-upper cover. See Rear-upper cover on page 31.
 - Speaker. See Speaker on page 33.
 - Top cover. See <u>Top cover on page 34</u>.
 - Rear door and rear-lower cover. See Rear door and rear-lower cover on page 41.
- Remove two screws (callout 1) and the black plastic cover (callout 2).






Disconnect five wire-harness connectors (callout 1). Remove the wire harness from the guides (callout 2 and callout 3) and one retainer (callout 4).

Figure 1-118 Remove the fuser (2 of 4)




Remove four screws (callout 1).


Figure 1-119 Remove the fuser (3 of 4)



5. Remove the fuser.

△ CAUTION: Handle the fuser carefully. The sensors that are mounted to the output side of the fuser can be easily dislodged. When the fuser is reinstalled, make sure that the sensors are present, and correctly fastened to the fuser assembly.






Document feeder components

NOTE: This section describes replacement and removal of individual document feeder components. To remove the complete document-feeder and scanner assembly, see Document-feeder and scanner assembly on page 28.


Document feeder separation pad


1. Open the document feeder top cover.






2. Release one tab, and then fully open the document feeder cover.






3. Remove six screws (callout 1).

Figure 1-123 Remove the document feeder separation pad assembly (3 of 7)





4. Release four tabs (callout 1) on the document feeder core cover.

Figure 1-124 Remove the document feeder separation pad assembly (4 of 7)





5. Remove the document feeder core cover (callout 1) from the base.






6. Push up on the separation pad assembly to release two pins (callout 1), and then slightly slide assembly in the core cover to release the remaining two pins (callout 2).






7. Remove the separation pad assembly from the core cover.

Figure 1-127 Remove the document feeder separation pad assembly (7 of 7)




Document feeder input tray

1. Open the document feeder cover.






Hold the scanner cover down, and then pull up on the document feeder tray to release two tabs, lift the document feeder tray up, and then remove it.





Document feeder cover


1. Open the document feeder cover.






2. Release one tab (callout 1), and then fully open the document feeder cover.

Figure 1-131 Remove the document feeder cover (2 of 3)



Release the hinges (callout 1), and then remove the document feeder cover.






Document feeder pick arm assembly


- Remove the following components:
 - Document feeder input tray. See <u>Document feeder input tray on page 87</u>.
 - Document feeder cover. See <u>Document feeder cover on page 88</u>.
- 2. Release two tabs (callout 1) on each end of the inner cover (for a total of four tabs), and then lift the inner cover out of the outer cover.

Figure 1-133 Remove the document feeder pick arm assembly (1 of 4)




3. Remove the pick extension shaft (callout 1).

Figure 1-134 Remove the document feeder pick arm assembly (2 of 4)




4. Release one tab (callout 1).

Figure 1-135 Remove the document feeder pick arm assembly (3 of 4)



5. Disconnect the spring that is underneath the pick arm assembly (callout 1), and then rotate the pick arm assembly to remove it (callout 2).


Figure 1-136 Remove the document feeder pick arm assembly (4 of 4)



Document feeder core assembly


- 1. Remove the following components:
 - Document feeder input tray. See <u>Document feeder input tray on page 87</u>.
 - Document feeder cover. See <u>Document feeder cover on page 88</u>.
- 2. Release one tab (callout 1), and then remove the document feeder cable cover (callout 2).

Figure 1-137 Remove the document feeder core assembly (1 of 3)



3. Remove one FFC using the blue tab (callout 1).


Figure 1-138 Remove the document feeder core assembly (2 of 3)



TIP: The orientation of the FFC is important. When reinstalling it, make sure the blue tab is toward the product right side. If the FFC is installed upside down, the document feeder will not work.

Release one hinge (callout 1), and then remove the document feeder core assembly.






Post scan pinch rollers

- 1. Remove the following components:
 - Document feeder input tray. See <u>Document feeder input tray on page 87</u>.
 - Document feeder cover. See <u>Document feeder cover on page 88</u>.
 - Document feeder core. See <u>Document feeder core assembly on page 92</u>.
- 2. Remove the post scan pinch rollers (callout 1).


Figure 1-140 Remove the post scan pinch rollers



Document feeder base assembly


- 1. Remove the following components:
 - Document feeder input tray. See <u>Document feeder input tray on page 87</u>.
 - Document feeder cover. See <u>Document feeder cover on page 88</u>.
 - Document feeder core. See Document feeder core assembly on page 92.
- 2. Release the adhesive FFC protector on the document feeder base (callout 1).
- Reinstallation tip Use two-sided tape to replace the FFC protector during reassembly.






- 3. Pull forward on the center tab on one of the solar locks to release the lock (callout 1), and then pull the solar lock straight down to remove it (callout 2). Repeat the procedure for the other solar lock.
 - TIP: The solar locks can be difficult to remove. You might need to use a small flat-blade screwdriver to gently pry the two side tabs in order to release the solar lock from the groove in the document feeder hinge.

Figure 1-142 Remove the document feeder base assembly (2 of 3)



- 4. Open the document feeder base, and then carefully remove it from the scanner assembly.
 - △ CAUTION: Do not damage the FFC (callout 1) that runs through the document feeder base. Carefully feed the FFC through the slot during removal and during replacement.


Figure 1-143 Remove the document feeder base assembly (3 of 3)



Document feeder floating hinges

- 1. Remove the following components:
 - Document feeder input tray. See <u>Document feeder input tray on page 87</u>.
 - Document feeder cover. See <u>Document feeder cover on page 88</u>.
 - Document feeder core. See Document feeder core assembly on page 92.
 - Document feeder base assembly. See <u>Document feeder base assembly on page 95</u>.
- 2. Release two tabs on each hinge (callout 1), and then remove each hinge (callout 2).

Figure 1-144 Remove the document feeder floating hinges



2 Solve problems

- Menu map
- Tools for troubleshooting
- Paper feeds incorrectly or becomes jammed
- Service mode functions
- Solve fax problems
- Product updates

ENWW 99

Menu map

Use the following procedure to print a control-panel menu layout map.

- From the Home screen, touch the Setup \(\) button.
- 2. Touch the Reports button.
- 3. Touch the Menu Structure button.

Tools for troubleshooting

Component diagnostics

LED diagnostics

Network LEDs

The onboard network solution has two network port LEDs. When the product is connected to a properly working network through a network cable, the yellow LED indicates network activity, and the green LED indicates the link status. A blinking yellow LED indicates network traffic. If the green LED is off, a link has failed.

For link failures, check all of the network cable connections. In addition, you can try to manually configure the link settings on the onboard network solution by using the product control-panel menus.

- Touch the Setup \(\) button.
- 2. Scroll to and touch the Network Setup menu.
- 3. Touch the Link Speed menu.
- 4. Select one of the following options.

Setting	Description
Automatic	The print server automatically configures itself for the highest link speed and communication mode allowed on the network.
10T Half	10 megabytes per second (Mbps), half-duplex operation
10T Full	10 Mbps, full-duplex operation
100TX Half	100 Mbps, half-duplex operation
100TX Full	100 Mbps, full-duplex operation

5. Touch the OK button. The product turns off and then on.

Control panel LEDs

The state of the Ready light and Attention light on the product signal the product status. The following table outlines the possible control-panel light states.

NOTE: Wireless models have a blue LED that illuminates when the product wireless function is enabled and available.

Product state	Ready light state	Attention light state
Initializing	Blinking	Blinking
Ready	On	Off
Receiving data/processing job or cancelling job	Blinking	Off
Error message	Off	Blinking
Fatal error (49 or 79 error) ¹	On	On

¹ The product restarts after one of these errors occurs.

Control-panel diagnostics

The product includes diagnostic tests for the control panel.

Test the control-panel display

- 1. Touch the Setup & button.
- 2. Touch the left arrow button ◄, and then quickly touch the Cancel 🗙 button.
- 3. Touch the Setup \triangleleft button to return to the main menus.
- 4. Open the 2ndary Service menu.
- 5. Open the **Display test** menu.

Test the control-panel buttons

- Touch the Setup \(\) button.
- 2. Touch the left arrow button ◀, and then quickly touch the Cancel ★ button.
- 3. Touch the Setup \checkmark button to return to the main menus.
- 4. Open the 2ndary Service menu.
- 5. Open the **Button test** menu.

Engine Diagnostics

Engine test

- 1. With the product off, open the front and rear doors.
- 2. Turn the power on, and close both doors within ten seconds.
- 3. An engine test page (a page containing multiple horizontal colored lines) will print.

Repetitive image defects

If the product output has a consistent, repetitive defect, then use the table in this section to determine which part needs to be replaced based on the measured distance between the repetitions of the defect.


NOTE: The following table replaces the graphical repetitive defect ruler. You can make your own ruler by using these measurements. For the most accurate results, use a metric ruler.

Table 2-1 Repetitive image defects

Distance between identical defects	Component	Notes	
22.3 mm (0.87 in)	Developer roller (one rotation)	Appears in a single color plane.	
26.7 mm (1.05 in)	Charger roller	Appears in a single color plane.	
28.5 mm (1.12 in)	Developer RS roller (one rotation)	Inside developer, this roller removes and supplies toner to the developer sleeve.	
44.0 mm (1.73 in)	Registration roller		
56.5 mm (2.22 in)	Fuser film (one rotation)	Appears in all color planes.	
56.8 mm (2.23 in)	Fuser pressure roller (one rotation)	Appears in all color planes.	
57.0 mm (2.24 in)	Transfer roller	Appears in all color planes.	
69.0 mm (2.71 in)	Cartridge-to-cartridge spacing	Distance between each color image drum	
75.8 mm (2.98 in)	Image drum (one rotation)	Appears in a single color plane and might be either a dark or white spot.	
633.6 mm (24.94 in)	ITB	Because the ITB is longer than a page, you might have to look at multiple pages to determine if repetitive defect is present.	

Diagrams

Plug/jack locations



DC controller **PCA**

Figure 2-1 DC controller connectors




Table 2-2 DC controller connectors

Item	Description
J102	Low-voltage power supply (+24 V)
J103	Low-voltage power supply (+3.3 V)
J104	Thermistor (TH802)
J105	Fuser power supply
J107	Formatter
J108	Laser driver PCA
J109	Scanner motor (M704)
J110	Fuser motor (M703)
J111	Pickup assembly motor (M702)
J112	Developing disengagement solenoid (SL706)
J113	Cassette pickup solenoid (SL705)
P115	High-voltage power supply


Table 2-2 DC controller connectors (continued)

Item	Description	
P116	Pickup assembly	
	Loop sensor (SR603)	
	Top-of-page sensor (SR602)	
	Cassette media present sensor (SR601)	
J118	Media width sensor (SR607)	
J119	ITB assembly density sensors	
J120	Developing home position sensor (SR606)	
J121	Main motor (M701)	
J124	Memory tags (e-labels)	

General timing charts (product base only)

Approximate timing in seconds.

Figure 2-2 Timing diagram



General circuit diagram (product base only)

Figure 2-3 Circuit diagram ∢ 0 5 4 3 2 1 13 Operation unit 22 Fax 1931 Cassette pickup solenoid SL705 2 +S4AV Saru Saru Earu WL Module 27 23 DC controller PCA Host USB SR610 Low-voltage power supply PCA 2 ITB unit Color / ITB p 9 29 Fuser power supply PCA

Print-quality troubleshooting tools

Print a Diagnostics Page

If the printed output has colored shadows, blurry graphics, or areas that have poor color, you might need to calibrate the product to align the colors. Use the Diagnostics Page to check the color alignment.

- On the product control panel, open the Reports menu.
- Select the Diagnostics Page item to print it.
- If the blocks of color on the page are not aligned with each other, calibrate the product.

Calibrate the product

- On the product control panel, open the System Setup menu.
- Open the Print Quality menu, and select the Color Calibration item.
- Select the Calibrate Now option.

Interpret the Print Quality Page

- On the product control panel, open the Reports menu.
- Select the Print Quality Page item to print it.

This page contains five bands of color, which are divided into four groups as indicated in the following illustration. By examining each group, you can isolate the problem to a particular print cartridge.



Section	Print-cartridge	
1	Yellow	
2	Cyan	

Section	Print-cartridge
3	Black
4	Magenta

- If dots or streaks appear in only one of the groups, replace the print cartridge that correlates with that group.
- If dots appear in more than one group, print a cleaning page. If this does not solve the problem, determine if the dots are always the same color; for example, if magenta dots appear in all five color bands. If the dots are all the same color, replace that print cartridge.
- If streaks appear in multiple color bands, contact HP. A component other than the print cartridge is probably causing the problem.

Control panel menus

Setup Menu

To open this menu, touch the Setup $\mbox{\ensuremath{\ensuremath{\triangleleft}}}$ button. The following sub menus are available:

- Reports
- Quick Forms
- Fax Setup
- System Setup
- Service
- Network Setup

Reports menu

Menu item	Description		
Demo Page	Prints a page that demonstrates print quality		
Menu Structure	Prints a control-panel menu layout map.		
Configuration Report	Prints a list of the product settings		
Supplies Status	Prints the print-cartridge status. Includes the following information:		
	Estimated percentage of cartridge life remaining		
	Approximate pages remaining		
	Part numbers for HP print cartridges		
	Number of pages printed		
	 Information about ordering new HP print cartridges and recycling used HP print cartridges 		
Network Summary	Displays status for:		
	Network hardware configuration		
	Enabled features		
	TCP/IP and SNMP information		
	Network statistics		
	 Wireless network configuration (wireless models only) 		
Usage Page	Displays the number of pages printed, faxed, copied, and scanned by the product		
PCL Font List	Prints a list of all installed PCL 5 fonts		
PS Font List	Prints a list of all installed PS fonts		
PCL6 Font List	Prints a list of all installed PCL 6 fonts		
Color Usage Log	Prints information about the color supply usage		
Service Page	Prints the service page		
	The service page includes information about supported paper types, copy settings, and other settings that are not included on the configuration page.		
Diagnostics Page	Prints diagnostic information about calibration and color quality		
Print Quality Page	Prints a page that helps solve problems with print quality		

Quick Forms menu

Menu item	Sub-menu item	Description
Notebook Paper	Narrow Rule	Prints pages that have preprinted lines
	Wide Rule	
	Child Rule	
Graph Paper	1/8 inch	Prints pages that have preprinted graph lines
	5 mm	
Checklist	1-Column	Prints pages that have preprinted lines with check boxes
	2-Column	
Music Paper	Portrait	Prints pages that have preprinted lines for writing music
	Landscape	

Fax Setup menu

Menu item	Sub-menu item	Sub-menu item	Description
Fax Set-Up Utility			This is a tool for configuring the fax settings. Follow the on-screen prompts and select the appropriate response for each question.
Basic Setup	Time/Date	(Settings for time format, current time, date format, and current date.)	Sets the time and date setting for the product.
	Fax Header	Enter your fax number.	Sets the identifying information that is sent to the receiving product.
		Enter company name.	Identifies the fax sender (optional)
	Answer Mode	Automatic*	Sets the type of answer mode. The following options are available:
		Manual TAM	 Automatic: The product automatically answers an incoming call on the configured number of rings.
		Fax/Tel	 Manual: The user must press the Start Fax button or use an extension phone to make the product answer the incoming call.
			 TAM: A telephone answering machine (TAM) is attached to the Auxilary phone port of the product. The product will not pick up any incoming call, but only listen for fax tones after the answering machine has picked up the call.
			• Fax/Tel: The product must automatically pick up the call and determine if the call is a voice or fax call. If the call is a fax call, the product handles the call as usual. If the call is a voice call, an audible synthesized ring is generated to alert the user of an incoming voice call.
	Rings to Answer		Sets the number of rings that must occur before the fax modem answers. The default setting is 5.
	Distinctive Ring	All Rings*	If you have distinctive ring phone service, use this item to configure how the product responds to incoming calls.
		Single Double	 All Rings: The product answers any calls that come through the telephone line.
		Triple	 Single: The product answers any calls that produce a single-ring pattern.
		Double and Triple	 Double: The product answers any calls that produce a double-ring pattern.
			Triple: The product answers any calls that produce a triple-ring pattern.
			 Double and Triple: The product answers any calls that produce a double-ring or triple-ring pattern.

Menu item	Sub-menu item	Sub-menu item	Description
	Dial Prefix	On	Specifies a prefix number that must be dialed when sending faxes from the product. If you turn this feature on,
		Off*	the product prompts you to enter the number and then it automatically includes that number every time you send a fax.
Advanced Setup	Fax Resolution	Standard	Sets the resolution for sent documents. Higher resolution images have more dots per inch (dpi), so they show more
		Fine*	detail. Lower resolution images have fewer dots per inch
		Superfine	and show less detail, but the file size is smaller and the fat takes less time to transmit.
		Photo	
	Lighter/Darker		Sets the darkness of outgoing faxes.
	Fit to Page	On*	Shrinks incoming faxes that are larger than the paper size set for the tray.
		Off	Set for the tray.
	Glass Size	Letter	Sets the default paper size for documents being scanned from the flatbed scanner.
		A4	
			NOTE: The default setting is determined by the choice of location during the initial product setup.
	Dialing Mode	Tone*	Sets whether the product should use tone or pulse dialing
		Pulse	
	Redial if Busy	On*	Sets whether the product should attempt to redial if the line is busy.
		Off	
	Redial if No Answer	On	Sets whether the product should attempt to redial if the
		Off*	recipient fax number does not answer.
	Redial if Comm. Error	On*	Sets whether the product should attempt to redial the recipient fax number if a communication error occurs.
	LITOI	Off	recipient lax number in a communication error occurs.
	Detect Dial Tone	On	Sets whether the product should check for a dial tone
		Off*	before sending a fax.
	Billing Codes	On	Enables the use of billing codes when set to On . A promp
		Off*	appears where you can enter the billing code for an outgoing fax.
	Extension Phone	On*	When this feature is enabled, you can press the 1-2-3
		Off	buttons on the extension phone to cause the product to answer an incoming fax call.
	Stamp Faxes	On	Sets the product to print the date, time, sender's phone
		Off*	number, and page number on each page of incoming faxes.

Menu item	Sub-menu item	Sub-menu item	Description
	Private Receive	On	Setting Private Receive to On requires you to set a
		Off*	product password. After setting the password, the following options are set:
			Private Receive is turned on.
			All old faxes are deleted from memory.
			 Fax forwarding is set to Off and is not allowed to be changed.
			All incoming faxes are stored in memory.
	Confirm Fax	On	Confirm a fax number by entering it a second time.
	Number	Off*	
	Allow Fax Reprint	On*	Sets whether incoming faxes are stored in memory for reprinting later.
		Off	reprinting later.
	Fax/Tel Ring Time	20	Sets the time, in seconds, after which the product should stop sounding the Fax/Tel audible ring to notify the user of
		30	an incoming voice call.
		40	
		70	
	Fax Speed	Fast(V.34)*	Sets the allowed fax communication speed.
		Medium(V.17)	
		Slow(V.29)	

System Setup menu

Menu item	Sub-menu item	Sub-menu item	Description
Language	(List of available control-panel display languages.)		Sets the language in which the control panel displays messages and product reports.
Paper Setup	Default Paper Size	Letter	Sets the size for printing internal reports, faxes, or any print job that does not specify a size.
		A4	NOTE: The default setting is determined by the choice of
		Legal	location during the initial product setup.
	Default Paper Type	Lists available paper types.	Sets the type for printing internal reports, faxes, or any print job that does not specify a type.
	Tray 1	Paper Type	Configures the size and type for the tray.
Paper Size			
	Paper Out Action	Wait forever*	Determines how the product reacts when a print job requires a paper size or type that is unavailable or when
		Cancel	the tray is empty.
		Override	 Wait forever: The product waits until you load the correct paper.
			 Override: Print on a different size paper after a specified delay.
			 Cancel: Automatically cancel the print job after a specified delay.
			 If you select either the Override or Cancel item, the control panel prompts you for the number of seconds to delay.
Print Quality	Color Calibration	Calibrate Now	Performs a full calibration.
		Power-On	Calibrate Now: Performs an immediate calibration.
		Calibration	 Power-On Calibration: Specify the length of time the product should wait after you turn it on before it calibrates.
Volume Settings	Alarm Volume		Set the volume levels for the product. The following options are available for each volume setting:
	Ring Volume		·
	Key-Press Volume		• Off
	Phone Line Volume		• Soft
	. Hone Line volume		Medium*
			• Loud

Menu item	Sub-menu item	Sub-menu item	Description
PowerSave Time	Sleep Delay	Off	Specifies the amount of idle time before the product enters
		1 Minute	sleep mode.
		15 Minutes*	
		30 Minutes	
		1 Hour	
		2 Hours	
Time/Date	(Settings for time format, current time, date format, and current date.)		Sets the time and date setting for the product.
Product Security	On Off*		Sets the product-security feature. If you select the On setting, you must set a password.
At Very Low	Black Cartridge	Stop	Sets how the product behaves when the black print cartridge reaches the very low threshold.
		Prompt Continue*	 Stop: The product stops printing until you replace the print cartridge.
			 Prompt: The product stops printing and prompts you to replace the print cartridge. You can acknowledge the prompt and continue printing.
			 Continue: The product alerts you that the print cartridge is very low, but it continues printing.
	Color Cartridges	Stop	Sets how the product behaves when one of the color print cartridges reaches the very low threshold.
		Prompt	Stop: The product stops printing until you replace the
		Continue	print cartridge.
		Print Black*	 Prompt: The product stops printing and prompts you to replace the print cartridge. You can acknowledge the prompt and continue printing.
			 Continue: The product alerts you that the print cartridge is very low, but it continues printing.
			 Print Black: When a color print cartridge becomes very low, the product prints in black only to prevent fax interruptions. To configure the product to print in color and use the remaining toner in the print cartridge past very low, follow these steps:
			 On the product control panel, touch the Setup button, and then touch the System Setup button.
			2. Touch the At Very Low button, and then touch the Color Cartridges button. Touch the Continue button.
			When you choose to replace the very low print cartridge, color printing resumes automatically.

Menu item	Sub-menu item	Sub-menu item	Description
User-Defined Low	Black		Type the percentage of estimated life remaining at which
	Cyan		the product alerts you that the print cartridge is low.
	Magenta		
	Yellow		
USB Flash Drive	On*		Enables or disables the USB flash drive.
	Off		
Color Copy	On*		Enables or disables color copying.
	Off		
Courier Font	Regular*		Sets Courier font values.
	Dark		

Service menu

Menu item	Sub-menu item	Sub-menu item	Description
Fax Service	Clear Saved Faxes		Clears all faxes in memory.
	Run Fax Test		Performs a fax test to verify that the phone cord is plugged in the correct outlet and that there is a signal on the phone line. A fax test report is printed indicating the results.
	Print T.30 Trace	Now	Prints or schedules a report that is used to troubleshoot fax
		Never*	transmission issues.
		If Error	
		At End of Call	
	Error Correction	On*	The error correction mode
		Off	allows the sending device to re-transmit data if it detects an error signal.
	Fax Service Log		The fax service log prints out the last 40 entries in the fax log.
Cleaning Page			Cleans the product when specks or other marks appear on printed output. The cleaning process removes dust and excess toner from the paper path.
			When selected, the product prompts you to load plain Letter or A4 paper in Tray 1. Touch the OK button to begin the cleaning process. Wait until the process completes. Discard the page that prints.
USB Speed	High*		Sets the USB speed for the USB connection to the
	Full		computer. For the product to actually operate at high speed, it must have high speed enabled and be connected to an EHCI host controller that is also operating at high speed. This menu item also does not reflect the current operating speed of the product.
Less Paper Curl	On		When printed pages are
	Off*		consistently curled, this option sets the product to a mode that reduces curl.

Menu item	Sub-menu item	Sub-menu item	Description
Archive Print	On		When printing pages that will
	Off*		be stored for a long time, this option sets the product to a mode that reduces toner smearing and dusting.
Firmware Datecode			Displays the current firmware datecode
Restore Defaults			Sets all settings to the factory default values

Network Setup menu

Menu item	Sub-menu item	Description
Wireless Menu (wireless models only)	Wireless Setup Wizard	Guides you through the steps to set up the product on a wireless network
	Wi-Fi Protected Setup	If your wireless router supports this feature, use this method to set up the product on a wireless network. This is the simplest method.
	Run Network Test	Tests the wireless network and prints a report with the results.
	Turn Wireless On/Off	Enables or disables the wireless network feature.
TCP/IP Config Automatic*	Automatic*	Automatic: The product automatically configures all the TCP/IP
	Manual	settings via DHCP, BootP or AutoIP.
mask, and default gateway. The control p specify values for each address section. A completed, the product prompts for addre	Manual: You can manually configure the IP address, subnet mask, and default gateway. The control panel prompts you to specify values for each address section. As each address is completed, the product prompts for address confirmation before moving to the next one. After all three addresses are set, the network reinitializes.	
Auto Crossover	On*	Enables or disables the use of a standard 10/100 network cable when the product is directly connected to a computer.
	Off	when the product is directly connected to a computer.
Network Services	IPv4	Enable or disable the IPv4 and IPv6 protocols. By default, each
	IPv6	protocol is enabled.
Link Speed	Automatic*	Sets the link speed manually if needed.
	10T Full	After setting the link speed, the product automatically restarts.
	10T Half	
	100TX Full	
	100TX Half	
Restore Defaults		Resets all network configurations to their factory defaults.

Function specific menus

The product features function-specific menus for copying, faxing, scanning, and using a USB flash drive. To open these menus, touch the button for that function on the control panel.

Copy Menu

To open this menu, touch the Copy button, and then touch the Settings... button.

NOTE: Settings that you change with this menu expire 2 minutes after the last copy completes.

Menu item	Sub-menu item	Sub-menu item	Description
ID Copy			Copies both sides of
NOTE: This item is available from the main Copy screen. You do not need to touch the Settings button to access it.			identification cards, or other small-size documents, onto the same side of one sheet of paper.
Number of Copies	(1–99)		Specifies the number of copies
Reduce/Enlarge	Original=100%		Specifies the size of the
	Legal to Letter=78%		сору.
	Legal to A4=83%		
	A4 to Letter=94%		
	Letter to A4=97%		
	Full Page=91%		
	Fit to Page		
	2 Pages per Sheet		
	4 Pages per Sheet		
	Custom: 25 to 400%		
Lighter/Darker			Specifies the contrast of the copy.
Optimize	Describe Original	Auto Select*	Specifies the type of conter
		Mixed	in the original document, so the copy is the best match
		Text	for the original.
		Picture	
Paper	Paper Size		Specifies the paper size and type.
	Paper Type		NOTE: The default paper size setting is determined by the choice of location during the initial product setup.
			The default paper type setting is plain.

Menu item	Sub-menu item	Sub-menu item	Description
Multi-Page Copy	Off*		When this feature is on, the
	On		product prompts you to load another page onto the scanner glass or to indicate that the job is complete.
Collation	On*		Specifies whether to collate copy jobs
	Off		сору јова
Draft Mode	Off*		Specifies whether to use draft-quality printing for
	On		copies
Image Adjustment	Lightness		Adjusts the image quality settings for copies
	Contrast		settings for copies
	Sharpen		
	Background Removal		
	Color Balance		
	Grayness		
Set as New Defaults			Saves any changes you have made to this menu as the new defaults
Restore Defaults			Restores the factory defaults for this menu

Fax Menu

To open this menu, touch the Fax button, and then touch the Fax Menu button.

Menu item	Sub-menu item	Sub-menu item	Description
Fax Reports	Fax Confirmation	On Every Fax	Sets whether the product
		On Send Fax Only	prints a confirmation report after a successful fax job.
		On Receive Fax Only	
		Never*	
	Include First Page	On*	Sets whether the product includes a thumbnail image
		Off	of the first page of the fax on the report.
	Fax Error Report	On Every Error*	Sets whether the product
		On Send Error	prints a report after a failed fax job.
		On Receive Error	
		Never	

Menu item	Sub-menu item	Sub-menu item	Description
	Print Last Call Report		Prints a detailed report of the last fax operation, either sent or received.
	Fax Activity Log	Print Log Now Auto Log Print	Print Log Now: Prints a list of the faxes that have been sent from or received by this product.
			Auto Log Print: Automatically prints a report after every fax job.
	Print Phone Book		Prints a list of the speed dials that have been set up for this product.
	Print Junk Fax list		Prints a list of phone numbers that are blocked from sending faxes to this product.
	Print Billing Report		Prints a list of billing codes that have been used for outgoing faxes. This report shows how many sent faxes were billed to each code. This menu item appears only when the billing codes feature is turned on.
	Print All fax Reports		Prints all fax-related reports.
Send Options	Send Fax Later		Allows a fax to be sent at a later time and date.
	Broadcast Fax		Sends a fax to multiple recipients.
	Fax Job Status		Displays pending fax jobs, and allows you to cancel pending fax jobs.
	Fax Resolution	Standard	Sets the resolution for sent
		Fine*	documents. Higher resolution images have more dots per
		Superfine	inch (dpi), so they show more detail. Lower resolution
		Photo	images have fewer dots per inch and show less detail, but the file size is smaller.
Receive Options	Print Private Faxes		Prints stored faxes when the private-receive feature is on. This menu item appears only when the private-receive feature is turned on. The product prompts you for the system password.

Menu item	Sub-menu item	Sub-menu item	Description
	Block Junk Faxes	Add Number	Modifies the junk fax list. The junk fax list can contain up to
		Delete Number	30 numbers. When the
		Delete All Numbers	product receives a call from one of the junk fax numbers,
		Print Junk Fax list	it deletes the incoming fax. It also logs the junk fax in the activity log along with jobaccounting information.
	Reprint Faxes		Prints the received faxes stored in available memory. This item is available only if you have turned on the Allow Fax Reprint feature in the Fax Setup menu.
	Forward Fax	On Off*	Sets product to send all received faxes to another fax machine.
	Polling Receive		Allows the product to call another fax machine that has polling send enabled.
Phone Book Setup	Individual Setup		Edits the fax phone book
	Group Setup		 speed dials and group-dial entries. The product supports up to 120 phone book entries, which can be either individual or group entries.
	Delete Entry	Deletes a specific phone book entry.	
	Delete All Entries	Deletes all entries in the phone book	
	Print Report Now	Prints a list of all the individual and group dial entries in the phone book.	
Change Defaults			Opens the Fax Setup menu.

Scan Menu

Menu item	Description
Scan to USB Drive	Scans a document and stores it as a .PDF file or .JPEG image on the USB flash drive.

USB Flash Drive

The following types are supported:

- .PDF
- .JPG

Menu item	Description
Print Documents	Prints documents stored on the USB drive. Use the arrow buttons to scroll through the documents. Touch the names of documents that you want to print.
	Touch the summary screen to change settings such as the number of copies, the paper size, or the paper type.
	Touch the Print button when you are ready to print the documents.
View and Print Photos	Previews photos on the USB drive. Use the arrow buttons to scroll through the photos. Touch the preview image for each photo that you want to print. You can adjust the settings, and you can save the changes as the new default settings. When you are ready to print the photos, touch the Print button.
Scan to USB Drive	Scans a document and stores it as a .PDF file or .JPEG image on the USB flash drive.

Interpret control-panel messages

Control panel message types

Alert and warning messages appear temporarily and might require you to acknowledge the message by touching the OK button to resume or by touching the Cancel \times button to cancel the job. With certain warnings, the job might not complete or the print quality might be affected. If the alert or warning message is related to printing and the auto-continue feature is on, the product will attempt to resume the printing job after the warning has appeared for 10 seconds without acknowledgement.

Critical error messages can indicate some kind of failure. Turning off and then turning on the power might fix the problem. If a critical error persists, the product might require service.

Control panel messages

10.100X Supply Memory Error

Recommended action

- 1. Verify that connector J124 on the DC controller is firmly seated.
- 2. Replace the DC controller.

49 Error, Turn off then on

Recommended action

- 1. Turn off the power by using the power switch, wait at least 30 seconds, and then turn on the power and wait for the product to initialize.
- If the error persists, replace the formatter.

50.x Fuser Error

Recommended action

- 1. Verify that connectors J104 and J110 on the DC controller are seated firmly.
- 2. Replace the fuser.
- 3. Replace the fuser power supply.

79 Error Turn off then on

Recommended action

- 1. Turn off the power by using the power switch, wait at least 30 seconds, and then turn on the power and wait for the product to initialize.
- 2. If a surge protector is being used, remove it. Plug the product directly into the wall socket. Use the power switch to turn the product on.
- 3. Replace the formatter.

Communication error.

Recommended action

Replace the fax card.

Document feeder jam. Clear and reload.

Recommended action

- 1. Clear the jam.
- If the error persists, replace the document feeder pickup roller assembly.

Document feeder mispick. Reload

Recommended action

- Remove the paper from the document feeder tray, and then reload it.
- If the error persists, try the following solutions:
 - Replace the document feeder pickup arm assembly. a.
 - b. Replace the document feeder core assembly.
 - Replace the document feeder assembly. C.

Door open

Recommended action

- Make sure that the door is completely closed.
- If the error persists, try the following solutions:
 - Replace the print cartridge drawer.
 - b. Replace the DC controller.

Engine Communication Error

Recommended action

- Verify that connector J107 on the DC controller is seated firmly.
- Replace the DC controller.

Engine error. Press OK to continue.

Recommended action

If the error persists, replace the DC controller.

Fax receive error.

Recommended action

If the error persists, replace the fax card.

Fax Send error.

Recommended action

If the error persists, replace the fax card.

Jam in (area), Open door and clear jam

Recommended action

- 1. Verify the pickup roller, and separation roller are working correctly and not damaged. If necessary, replace the rollers.
- 2. Verify that connector J116 on the DC controller is firmly seated.

Jam in Tray 1, Clear jam and then press OK

Recommended action

- 1. Clear the jam, and then follow the control panel instructions.
- 2. If the error persists, try the following solutions:
 - **a.** Verify the pickup roller and separation roller are working correctly. If necessary, replace the rollers.
 - **b.** If the error persists during print jobs, verify that the connector in DC controller connector J113 is firmly seated.
 - **c.** If the error persists during copy jobs, verify that the connector in DC controller connector J111 is firmly seated.
 - **d.** Replace the product.

Load paper

Recommended action

- Replace the cassette (paper tray).
- Verify that all eighteen DC controller connectors are firmly seated.

No dial tone.

Recommended action

If the error persists, replace the fax card.

No fax answer. Canceled send.

Recommended action

If the error persists, replace the fax card.

No fax answer. Redial pending.

Recommended action

- 1. Perform an NVRAM initialization.
- 2. Update the firmware.

No fax detected.

Recommended action

- 1. Use the Service menu Restore Defaults function to reset the product.
- 2. Perform an NVRAM initialization.
- **3.** Update the firmware.
- 4. Replace the fax card.

Print failure, press OK. If error repeats, turn off then on.

Recommended action

- 1. Perform an NVRAM initialization.
- 2. Update the firmware.
- 3. Replace the formatter PCA.

Scanner error #, Turn off then on

Recommended action

• Scanner error 12, Turn off then on

Motor test failure. This error will only appear on the Error report. The document-feeder motor is not blocked from turning.

- 1. Clear any jammed paper from the document feeder.
- **2.** Turn the product off, and then on.
- **3.** If the error persists, replace the document-feeder scanner assembly.

Scanner error 13, Turn off then on

RAM Wall failure. This error appears on the control panel. The scanner motor or scanner module is obstructed.

- **1.** Turn the product off, and then on.
- 2. If the error persists, replace the document-feeder scanner assembly.

Scanner error 14, Turn off then on

LED test failure. This error will only appear on the Error report. The LED did not illuminate during initialization.

Replace the document-feeder scanner assembly.

Scanner error 17, Turn off then on

Scanner error. This error appears on the control panel. The scanner motor is obstructed.

Replace the document-feeder scanner assembly.

Scanning error Cannot connect

Recommended action

If the error persists, replace the formatter.

Event-log messages

The following product events do not produce a message that appears on the control panel. Instead, they are recorded in the event log. To print the event log, open the secondary service menu, select Service Reports, and then select Error Report.

Table 2-3 Event-log messages

13.0000 Paper jam 20.0000 Memory out 21.0000 Page misfeed or misplok 41.2000 Beam detect malfunction 41.3000 Unexpected size 50.1000 Low fuser temperature error 50.2000 Slow fuser error 50.3000 High fuser temperature error 50.4000 Fuser orive circuit error 50.7000 Fuser open error 50.8000 Low subthermistor fuser error 51.2000 Black scanner laser error 51.2000 Black scanner laser error 51.2000 Magenta scanner laser error 51.2300 Yellow scanner laser error 54.1200 Black density measurement abnormality 54.1200 Black density measurement abnormality 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1509 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta density measurement abnormality <tr< th=""><th>Event code</th><th>Description</th></tr<>	Event code	Description
21.0000 Page misfeed or mispick 41.2000 Beam detect malfunction 41.3000 Unexpected size 50.1000 Low fuser temperature error 50.2000 Slow fuser error 50.3000 High fuser temperature error 50.4000 Fuser drive circuit error 50.7000 Fuser open error 50.8000 Low subthermistor fuser error 50.9000 High subthermistor fuser error 51.2000 Black scanner laser error 51.2100 Cyan scanner laser error 51.2200 Magenta scanner laser error 51.2300 Yellow scanner laser error 54.1200 Black density measurement abnormality 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1501 Cyon CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow CPR pattern can't be read 54.1500 Yellow toner level sens	13.0000	Paper jam
Hard Hard	20.0000	Memory out
41.3000 Unexpected size 50.1000 Low fuser temperature error 50.2000 Slow fuser error 50.3000 High fuser temperature error 50.4000 Fuser drive circuit error 50.7000 Fuser open error 50.8000 Low subthermistor fuser error 50.9000 High subthermistor fuser error 51.2000 Black scanner laser error 51.2100 Cyan scanner laser error 51.2200 Magenta scanner laser error 51.2300 Yellow scanner laser error 54.0600 Density sensor error 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1501 Cyon CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1600 Magenta toner level sensor error 54.1600 Magenta toner lev	21.0000	Page misfeed or mispick
50.1000 Slow fuser temperature error 50.2000 Slow fuser error 50.3000 High fuser temperature error 50.4000 Fuser drive circuit error 50.4000 Fuser open error 50.7000 Fuser open error 50.8000 Low subthermistor fuser error 50.9000 High subthermistor fuser error 51.2000 Black scanner laser error 51.2000 Cyan scanner laser error 51.2100 Cyan scanner laser error 51.2200 Magenta scanner laser error 51.2300 Yellow scanner laser error 54.0600 Density sensor error 54.1200 Black density measurement abnormality 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1400 Color plane registration sensor error 54.1509 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Magenta toner level sensor error	41.2000	Beam detect malfunction
Slow fuser error 50.3000 High fuser temperature error 50.3000 Fuser drive circuit error 50.7000 Fuser open error 50.8000 Low subthermistor fuser error 50.9000 High subthermistor fuser error 51.2000 Black scanner laser error 51.2100 Cyan scanner laser error 51.2200 Magenta scanner laser error 51.2200 Magenta scanner laser error 51.2300 Yellow scanner laser error 54.100 Density sensor error 54.1200 Black density measurement abnormality 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1400 Color plane registration sensor error 54.1509 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Magenta toner level sensor error 54.1500 Magenta toner level sensor error	41.3000	Unexpected size
Fuser drive circuit error 50.4000 Fuser open error 50.7000 Fuser open error 50.8000 Low subthermistor fuser error 50.9000 High subthermistor fuser error 51.2000 Black scanner laser error 51.2100 Cyan scanner laser error 51.2200 Magenta scanner laser error 51.2300 Yellow scanner laser error 54.0600 Density sensor error 54.1200 Black density measurement abnormality 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1204 Color plane registration sensor error 54.1509 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1500 Magenta toner level sensor error	50.1000	Low fuser temperature error
Fuser drive circuit error 50.7000 Fuser open error 50.8000 Low subthermistor fuser error 50.9000 High subthermistor fuser error 51.2000 Black scanner laser error 51.2100 Cyan scanner laser error 51.2200 Magenta scanner laser error 51.2300 Yellow scanner laser error 54.0600 Density sensor error 54.1200 Black density measurement abnormality 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1400 Color plane registration sensor error 54.1509 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1500 Magenta toner level sensor error	50.2000	Slow fuser error
Fuser open error 50.8000 Low subthermistor fuser error 50.9000 High subthermistor fuser error 51.2000 Black scanner laser error 51.2100 Cyan scanner laser error 51.2200 Magenta scanner laser error 51.2300 Yellow scanner laser error 54.0600 Density sensor error 54.1200 Black density measurement abnormality 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1400 Color plane registration sensor error 54.1599 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1500 Magenta toner level sensor error	50.3000	High fuser temperature error
50.8000 Low subthermistor fuser error 50.9000 High subthermistor fuser error 51.2000 Black scanner laser error 51.2100 Cyan scanner laser error 51.2200 Magenta scanner laser error 51.2300 Yellow scanner laser error 54.0600 Density sensor error 54.1200 Black density measurement abnormality 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1400 Color plane registration sensor error 54.1599 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1600 Magenta toner level sensor error	50.4000	Fuser drive circuit error
50.9000 High subthermistor fuser error 51.2000 Black scanner laser error 51.2100 Cyan scanner laser error 51.2200 Magenta scanner laser error 51.2300 Yellow scanner laser error 51.2300 Density sensor error 54.0600 Density sensor error 54.1200 Black density measurement abnormality 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1400 Color plane registration sensor error 54.1599 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Magenta toner level sensor error 54.1600 Magenta toner level sensor error	50.7000	Fuser open error
51.2000 Black scanner laser error 51.2000 Cyan scanner laser error 51.2200 Magenta scanner laser error 51.2300 Yellow scanner laser error 51.2300 Density sensor error 54.0600 Density sensor error 54.1200 Black density measurement abnormality 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1400 Color plane registration sensor error 54.1599 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Magenta toner level sensor error 54.1600 Magenta toner level sensor error 54.1600 Cyan toner level sensor error	50.8000	Low subthermistor fuser error
51.2100 Cyan scanner laser error 51.2200 Magenta scanner laser error 51.2300 Yellow scanner laser error 54.0600 Density sensor error 54.1200 Black density measurement abnormality 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1400 Color plane registration sensor error 54.1599 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1600 Magenta toner level sensor error	50.9000	High subthermistor fuser error
51.2200 Magenta scanner laser error 51.2300 Yellow scanner laser error 54.0600 Density sensor error 54.1200 Black density measurement abnormality 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1400 Color plane registration sensor error 54.1599 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1600 Magenta toner level sensor error	51.2000	Black scanner laser error
51.2300 Yellow scanner laser error 54.0600 Density sensor error 54.1200 Black density measurement abnormality 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1400 Color plane registration sensor error 54.1599 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1600 Magenta toner level sensor error 54.1700 Cyan toner level sensor error	51.2100	Cyan scanner laser error
54.0600 Density sensor error 54.1200 Black density measurement abnormality 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1400 Color plane registration sensor error 54.1599 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Magenta toner level sensor error 54.1600 Magenta toner level sensor error 54.1700 Cyan toner level sensor error	51.2200	Magenta scanner laser error
54.1200 Black density measurement abnormality 54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1400 Color plane registration sensor error 54.1599 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1600 Magenta toner level sensor error 54.1700 Cyan toner level sensor error	51.2300	Yellow scanner laser error
54.1201 Cyan density measurement abnormality 54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1400 Color plane registration sensor error 54.1599 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Magenta toner level sensor error 54.1600 Magenta toner level sensor error 54.1700 Cyan toner level sensor error	54.0600	Density sensor error
54.1202 Magenta density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1400 Color plane registration sensor error 54.1599 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1600 Magenta toner level sensor error 54.1700 Cyan toner level sensor error	54.1200	Black density measurement abnormality
Yellow density measurement abnormality 54.1203 Yellow density measurement abnormality 54.1400 Color plane registration sensor error 54.1599 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1600 Magenta toner level sensor error 54.1700 Cyan toner level sensor error	54.1201	Cyan density measurement abnormality
54.1400 Color plane registration sensor error 54.1599 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1600 Magenta toner level sensor error 54.1700 Cyan toner level sensor error	54.1202	Magenta density measurement abnormality
54.1599 Black CPR pattern can't be read 54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1600 Magenta toner level sensor error 54.1700 Cyan toner level sensor error	54.1203	Yellow density measurement abnormality
54.1501 Cyan CPR pattern can't be read 54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1600 Magenta toner level sensor error 54.1700 Cyan toner level sensor error	54.1400	Color plane registration sensor error
54.1502 Magenta CPR pattern can't be read 54.1503 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1600 Magenta toner level sensor error 54.1700 Cyan toner level sensor error	54.1599	Black CPR pattern can't be read
54.1503 Yellow CPR pattern can't be read 54.1500 Yellow toner level sensor error 54.1600 Magenta toner level sensor error 54.1700 Cyan toner level sensor error	54.1501	Cyan CPR pattern can't be read
54.1500 Yellow toner level sensor error 54.1600 Magenta toner level sensor error 54.1700 Cyan toner level sensor error	54.1502	Magenta CPR pattern can't be read
54.1600 Magenta toner level sensor error 54.1700 Cyan toner level sensor error	54.1503	Yellow CPR pattern can't be read
54.1700 Cyan toner level sensor error	54.1500	Yellow toner level sensor error
·	54.1600	Magenta toner level sensor error
54.1800 Black toner level sensor error	54.1700	Cyan toner level sensor error
	54.1800	Black toner level sensor error

Table 2-3 Event-log messages (continued)

Event code	Description
54.1900	Bad top-of-page (TOP) sensor
54.2100	Beam detect (BD) error
55.0000	Engine internal communication error
55.0601	DC controller NVRAM data error
55.0602	DC controller NVRAM access error
55.1000	DC controller memory error
59.0160	ITB or main motor rotation error (59.A0)
59.0192	Developer motor rotation error (59.C0)
59.0240	Transfer alienation failure (59.F0)
59.3000	Fuser motor startup error
59.4000	Fuser motor error
59.5000	Image drum motor startup error—black
59.5300	Image drum motor startup error—yellow
59.6000	Image drum motor rotation error- black
59.6300	Image drum motor rotation error- yellow
59.7000	Black developer motor startup error
59.7300	Yellow developer motor startup error
59.8000	Black developer motor rotation error
59.8300	Yellow developer motor rotation error
59.9000	Main motor start error

Paper feeds incorrectly or becomes jammed

- The product does not pick up paper
- The product picks up multiple sheets of paper
- Prevent paper jams
- Clear jams

The product does not pick up paper

NOTE: If this error persists, replace the pickup roller and separtation roller.

If the product does not pick up paper from the tray, try these solutions.

- Open the product and remove any jammed sheets of paper.
- Load the tray with the correct size of paper for your job.
- Make sure the paper guides in the tray are adjusted correctly for the size of paper. Adjust the guides so they are touching the paper stack without bending it.

The product picks up multiple sheets of paper

NOTE: If this error persists, replace the pickup roller and separtation roller.

If the product picks up multiple sheets of paper from the tray, try these solutions.

- Remove the stack of paper from the tray and flex it, rotate it 180 degrees, and flip it over. Do not fan the paper. Return the stack of paper to the trav.
- 2. Use only paper that meets HP specifications for this product.
- Use paper that is not wrinkled, folded, or damaged. If necessary, use paper from a different package.
- Make sure the tray is not overfilled. If it is, remove the entire stack of paper from the tray, straighten the stack, and then return some of the paper to the tray.
- Make sure the paper guides in the tray are adjusted correctly for the size of paper. Adjust the guides so they are touching the paper stack without bending it.

Prevent paper jams

NOTE: If the product is being serviced because of excessive paper jams, do the following:

Remove all of the paper from the product, and then clean the product. Test the product by printing with paper that meets HP specifications.


To reduce the number of paper jams, try these solutions.

- Use only paper that meets HP specifications for this product.
- Use paper that is not wrinkled, folded, or damaged. If necessary, use paper from a different package.
- Use paper that has not previously been printed or copied on.
- Make sure the tray is not overfilled. If it is, remove the entire stack of paper from the tray, straighten the stack, and then return some of the paper to the tray.
- Make sure the paper guides in the tray are adjusted correctly for the size of paper. Adjust the guides so they are touching the paper stack without bending it.
- Make sure that the tray is fully inserted in the product.

Clear jams

Jam locations

Jams can occur in these locations:




1	Document feeder
2	Output bin
3	Tray 1
4	Rear door

Loose toner might remain in the product after a jam. This problem typically resolves itself after a few sheets have been printed.

Clear jams from the document feeder


1. Turn the product off.



Open the document feeder cover.



3. Lift the document feeder mechanism, and gently pull the jammed paper out.



4. Close the document feeder cover.




Clear jams from the input tray


△ CAUTION: Do not use sharp objects, such as tweezers or needle-nose pliers, to remove jams. Damage caused by sharp objects is not covered by the warranty.

When removing jammed paper, pull it straight out from the product. Pulling jammed paper out of the product at an angle can damage the product.

- NOTE: Depending on where the jam is located, some of the following steps might not be necessary.
- Remove Tray 1, and lift the jam access door above the tray.




With both hands, grasp the paper, and carefully pull it free from the product.



3. Open the rear door.


CAUTION: The fuser, located in the back of the product, is hot. Wait for the fuser to cool before continuing.



With both hands, grasp the paper, and carefully pull it free from the product.



5. Reinsert the tray.



Close the rear output door.



- Print a cleaning page, which removes excess toner from the paper path.
 - **a.** From the Home screen, touch the Setup ⋄ button.
 - **b.** Touch the Service menu.
 - **c.** Touch the Cleaning Page button.
 - **d.** Load plain letter or A4 paper when you are prompted.
 - e. Touch the OK button to begin the cleaning process.

A page feeds through the product slowly. Discard the page when the process is completed.

Clear jams from the output bin

- △ CAUTION: Do not use sharp objects, such as tweezers or needle-nose pliers, to remove jams. Damage caused by sharp objects will not be covered by the warranty.
- With both hands, grasp the paper, and carefully pull it free from the product.



Service mode functions

Secondary service menu

Use the secondary service menu to print service-related reports and to run special tests. Customers do not have access to this menu.

Open the secondary service menu

- 1. Touch the Setup \(\) button.
- 2. Touch the middle of the screen along the left-hand edge (callout 1), and then immediately touch the lower-right corner (callout 2) of the screen.



- 3. When the Home screen appears, touch the Setup \checkmark button.
- 4. Touch the 2ndary Service button to open the menu.
 - TIP: When you are finished with the 2ndary Service menu, touch the lower-right corner of the screen until the **Job settings cleared.** message appears on the Home screen. This step removes the 2ndary Service option from the Setup Menu.

Secondary service menu structure

Table 2-4 Secondary service menu

Menu item	Sub-menu item	Description
Service Reports	Cont. Self-Test	This item prints a continuous configuration page.
	Error report	This item prints an error report that contains the last 5 instances of 49 Error , Turn off then on or 79 Error Turn off then on errors.
Location	A list of available locations appears	This item sets certain product parameters that are dependent on the location, such as the default paper size and the symbol set.
		Scroll to the appropriate location and select Yes to set the location. The product automatically restarts after you change the location.

ENWW Service mode functions 143

Table 2-4 Secondary service menu (continued)

Menu item	Sub-menu item	Description
Display test		This test verifies that the LEDs and characters on the control-panel display function correctly.
		At the beginning of the test, each of the LEDs is turned on one-at-time. Touch the OK button to continue to the next LED.
		After the LED test is complete, the character test begins by testing the pixels on each line. Then, each of the 255 characters is displayed in groups of 16. Touch the OK button to continue to the next group of 16 characters. You can cancel the test at any time by touching the Cancel X button.
Button test		This test verifies that the control-panel buttons function correctly. The display prompts you to press each button.
Color Cal.	Adjust color	This item adjusts density settings for contrast, highlights, midtones, and shadows. Adjust each color individually.
	Timing	This item specifies how frequently the product should automatically perform a color calibration. The default setting is 48 hours. You can turn automatic calibration off.
PBX ring detect	On or Off	Configure the PBX ring detect setting.
Clean Belt		This item runs additional belt-cleaning cycles.
Pick roller		This item puts the pickup roller in position for replacement.

Product resets

The product resets—Restore Defaults and the NVRAM initialization—perform the same function. If possible, use the Restore Defaults function in the Service menu. If that menu is not accessible, use the NVRAM sequence.

Restore the factory-set defaults

- △ CAUTION: Restoring the factory-set defaults returns all of the product and network settings to the factory defaults, and it also clears the fax header name, phone number, and any stored faxes in the product memory. This procedure also clears the fax phone book, and deletes any pages that are stored in the memory. The procedure then automatically restarts the product.
 - On the product control panel, touch the Setup \(\) button.
 - Scroll to and touch the Service menu.
 - 3. Scroll to and touch the Restore Defaults button, and then touch the OK button.

The product automatically restarts.

NVRAM initialization

Performing an NVRAM initialization resets the following settings and information:

- All menu settings are reset to factory default values.
- All localization settings, including language and country/region, are reset.
- △ CAUTION: All onboard network settings are also reset. Be sure to print a configuration page before restoring defaults. Make note of the IP address that is listed on the Jetdirect configuration page. You might need to restore the IP address after an NVRAM initialization.

After performing an NVRAM initialization, reconfigure any computers that print to this product. Uninstall and then reinstall the product software on the computers.

- 1. Turn the product off.
- 2. Touch the right arrow button. Hold this button as you turn the product on.
- NOTE: The right arrow button is not visible when the product is off, but it is still active. Note its position before you turn off the product.
- 3. When **Permanent storage init.** appears on the display, release the right arrow button.

When the product has finished the NVRAM initialization, it returns to the Ready state.

ENWW Service mode functions 145

Solve fax problems

Troubleshoot fax codes and trace reports

View and interpret fax error codes

Use fax error codes from the fax activity log to solve problems with the product fax features.

Table 2-5 Fax receive error codes

Error code	Description	Solution
200	The fax session has completed without errors.	N/A
221	User has touched the Cancel X button, causing the fax session to be prematurely halted.	Have the sender resend the fax.
222	The receiving product has answered a call but has been unable to detect the presence of a calling fax product for one of the following reasons:	 Confirm that the sender is a fax product and not a voice caller—typically you must rely on the sender informing the caller that the fax session is failing.
	 Typically this will be due to the receiving fax product answering a voice call. The sender canceled the fax transmission by touching the Cancel button immediately prior to, or just as the receiving product answered the call. The sending product automatically ended the call immediately prior to, or just as the receiving product answered the call. The sending (sending) fax product determined there was a feature incompatibility between the two and disconnected immediately before transmitting any further fax tones or T.30 frames. (This is very rare.) 	 If the sending product ends the call just as the receiving product starts reception, reduce the ring count after which the receiving product answers. Alternatively suggest that the sender manually dials to the receiving product and then manually starts the fax session, by touching the Start Fax button once fax tones have been heard from the receiving product. Confirm that the sender is not inadvertently attempting to poll transmit from the receiving product, instead of transmitting to the receiving product. Reconfigure the receiving fax product to use different configuration settings, toggle the ECM state, and/or select a slower reception speed.
223 (ECM error)	The receiving product has been unable to receive an entire page even after multiple attempts to rereceive the parts of the page that contain errors. This is usually due to extremely poor line conditions.	 Reattempt the fax reception at a different time when telephone line conditions have improved. If the error persists, disable ECM. Errors may still occur, and may result in degraded image quality on the received page. However, the ability to receive the entire document will be improved.
224	The receiving product has received one or more pages with excessive errors. This is usually due to extremely poor line conditions. Error correction is not used during this session so errors are not corrected.	Reattempt the fax reception at a different time when telephone line conditions have improved.
225	The sending product has attempted to initiate a sending diagnostic session with this product even though sending diagnostic access is disabled.	Enable the sending diagnostics capability on the receiving product.

Table 2-5 Fax receive error codes (continued)

Error code	Description	Solution
226	The sending product has attempted to initiate a sending diagnostic session with this product but the sending diagnostic versions supported by the two products are incompatible.	None. Sending diagnostics cannot occur between products with incompatible sending versions.
227	The sending product has attempted to initiate a fax session at a speed and modulation that is not supported by the receiving product.	Reconfigure the receiving product to receive at a slower speed.
228	The sending product has attempted to initiate a poll transmission from the receiving product even though the receiving product is not configured for poll transmission.	 Confirm that polling by the sender is desired. It is possible that the sender has inadvertently attempted to poll. If this is the case reattempt a normal transmission from the sending product.
		If polling by the remote user was desired, confirm that the receiving product was correctly configured for poll transmission.
229	The sending product has attempted to initiate a secure poll transmission from the receiving product but has not provided a valid password.	If the sender is the desired recipient for the polled document, confirm that the sender has the correct password, and that the receiving product is configured with the same password.
230	The sending product has attempted to initiate an operation that requires error correction but has not selected error correction for the session.	Enable ECM on both the receiving product and the sending product.
231	The sending product has attempted to initiate a transmission to the receiving product even though the capability to receive is disabled at the receiving product.	Ensure that the receiving product is capable of receiving a document. Check that paper is correctly loaded, paper is not jammed within the product, and any other system abnormalities have been cleared.
232	One of the following has occurred:	Re-attempt the fax reception at a different
233 and 234	A communication failure has occurred	time when telephone line conditions have improved.
235 and 236 (ECM error)	between the two products.The user at the remote product may have	If the error persists, and error correction is in use for the fax session, disable ECM.
237	touched the Cancel X button.	use for the lax session, disable Low.
	 The power at the remote product has been interrupted or deliberately turned off, causing the fax session to be interrupted. 	
238	The sending fax product sent an unexpected	N/A
239–241	 communication. This is a defect in the sending product. 	
242	The sending fax product is attempting to receive instead of send. Both products have attempted to start a reception at the same time. It is possible to accidentally initiate a fax reception after dialing on many products, if there is no paper in the product or if the paper is not correctly loaded and cannot be sensed by the appropriate document sensor.	Ensure that a document is ready and correctly loaded in the sending fax product and that the sending product is attempting to initiate a transmission and not a reception.

Table 2-5 Fax receive error codes (continued)

Error code	Description	Solution
243 and 244	 One of the following has occurred: The user of the remote product has touched the Cancel button, causing the session to be prematurely terminated. The sending fax product determined there was a feature incompatibility between the two products and has terminated the session. An example would be when the receiving product wanted to initiate polling, but the sending product did not support this mode of operation. 	 Confirm that the sender is not inadvertently attempting to poll transmit from the receiving product, instead of transmitting to the receiving product. This mode of operation must be specially configured on the receiving product. If poll transmission from the receiving product is the desired mode of operation, confirm that the receiving product has been configured for this operation. Reconfigure the receiving fax product to use different configuration settings, toggle the ECM state, and/or select a slower reception speed.
245 and 246 (ECM error)	The user of the sending product has touched the Cancel \times button, causing the session to be prematurely terminated. The receiving product has been "holding off" the remote product during reception of a large and/or complex document due to lack of available memory. This hold-off time has exceeded the timeout (typically 60 seconds) used by the sending product, and it has terminated the session.	 If the document was large, ask the sender to retransmit the document as two or more smaller documents. Disable ECM and reattempt the fax reception.
247-251	The sending product appears to be "stuck on."	N/A
252	Telephone line conditions were too poor to receive a fax.	 Reattempt the fax reception at a later time when line conditions may have improved. Configure the receiving product to start reception at a lower speed. If the receiving product received successfully several pages of a larger document, ask the
253	The sending product has attempted to initiate a page transmission using a page width that is not supported by the receiving product.	sender to transmit the document in several smaller parts. Ask the sender to reconfigure the fax product to transmit using a "normal" (letter/A4) page width.

Table 2-5 Fax receive error codes (continued)

Error code	Description	Solution
281	The receiving product has not received any data at the start of a page during non-ECM reception, although the modem has not detected a sending disconnect. The sending product is probably transmitting fill bytes instead of data and has either jammed or broken.	Reattempt the fax reception after first requesting that the sender check the sending product.
282	The receiving product has not received any data at the start of a page during ECM reception although the modem has not detected a sending disconnect. The sending product is probably transmitting sync frames instead of data and has either jammed or broken.	
283	The receiving product has detected that the modem carrier has stopped. Either the line has been disconnected or the sending product has aborted the transmission.	-
284	The receiving product has not received any data during non-ECM page reception and a timeout failure has occurred. The sending product is probably transmitting fill bytes instead of data and has either jammed or broken.	-
285	The receiving product has stopped receiving any data during an ECM page reception although the modem has not detected a sending disconnect. The sending product is probably transmitting sync frames instead of data and has either jammed or broken.	-
286	The sending product has transmitted invalid data. The receiving product has received frames with errors during an ECM reception and requested retransmission of the errored frames. The data that is resent does not correspond to the data that was requested. This is an implementation error from the sending product.	Disable ECM and reattempt the reception.
290	The sending product has attempted to renegotiate the session mode from ECM to non-ECM between pages. This operation is not supported and the session has been abandoned.	Reattempt the fax reception and split the document into two portions corresponding to the ECM and non-ECM portions. Some products will attempt to use non-ECM for photo mode, so this may be associated with a between-page encoding change to support photo mode.
291	This is not a communication error and it is not expected that this error will occur under non-development scenarios. Reception has failed because the receiving product is unable to open a file to receive data into. May be associated with low memory, although low memory should be handle more gracefully than this.	If the error persists, reinitialize the product.
292	The sending product has attempted to renegotiate the encoding mode from non-JPEG to JPEG. This operation is not supported and the session has been abandoned.	Reattempt the fax reception and split the document into two portions corresponding to the JPEG and non-JPEG portions. Some products will attempt to use JPEG for photo mode, so this may be associated with a between-page encoding change to support photo mode.

Table 2-6 Fax send error codes

300 311	Fax session has completed without errors	N/A
311		
	The user of the receiving product has touched the Cancel X button, causing the session to be prematurely halted before all pages have been transmitted.	Resend the fax.
312	A sending fax product has failed to answer the call. Specifically fax tones or the fax handshake from a sending product has not been detected. Typically this is due to the user calling the wrong number, the correct number has been called but the product has been configured not to answer, or the sending product has temporarily disabled answering due to a condition such as lack of paper or a paper jam.	Confirm the sending fax product is ready to receive a document and reattempt the transmission.
313	A busy signal has been detected each time the receiving product has attempted to call the sending product.	Reattempt the fax transmission at a later time when the line is no longer busy.
314	The receiving product has attempted to initiate a sending diagnostic session but has detected that sending diagnostics are disabled at the sending product.	Enable sending diagnostics on the sending product.
315	The receiving product has attempted to initiate a sending diagnostic session but has detected that the sending diagnostic version supported by the sending product is incompatible.	No solution. Sending diagnostics cannot occur between products with incompatible sending versions.
316	The receiving product is setup to initiate document transmission, but it has detected that the sending product is not able to receive a document. This error should be very rare since normally a sending product will not answer if it cannot receive a document. On of the few exceptions to this would occur if the sending product was configured to poll transmit a document but was unable to receive.	Configure the sending product for reception. Typically the sender should ensure paper is loaded in the product, paper jams are fixed, and any other system abnormalities are cleared.
317	The sending product cannot support a fax reception at any speed or modulation that is supported by the receiving product.	N/A
318	The sending product cannot support a fax reception at the page width selected by the receiving product.	N/A
319	The receiving product has attempted to initiate a binary file transfer (BFT) but has detected that the sending product does not support this mode of operation.	Do one of the following: Enable the BFT capability on the sending product if it is supported. Retransmit the document as a normal fax.

Table 2-6 Fax send error codes (continued)

Error code	Description	Solution
320	The receiving product is set up to initiate poll reception with a sending product, but it has detected that the sending product is not configured to do this. Poll transmission from a sending product is typically configured on a session-by-session basis.	 Confirm that the receiver really wants to attempt a poll reception. If not, reconfigure the receiving product for a normal fax transmission Configure the sending product for poll transmission. The sender must load a document to transmit and then configure the product for polling.
321	There was a communication error with the receiving fax product due to poor telephone line conditions.	Reattempt the fax transmission at a different time when telephone line conditions have improved.
322–324	Telephone line conditions were too poor to send a fax.	Reattempt the fax transmission at a differentime when telephone line conditions have improved.
		If the session fails after transmitting several pages of a large document, retransmit the document as several smaller documents.
325-328 (ECM error)	Telephone line conditions were very poor.	 Reattempt the fax transmission at a differentime when telephone line conditions have improved.
		 If the error persists, disable ECM. Errors may still occur, and may result in a degrade image quality on the received page. However, the ability to transmit the entire document will be improved.
329–331	The sending product has reported that one or more pages have been received (non-ECM mode) with excessive errors. This error does not result in the session being terminated immediately.	 Reattempt the fax transmission at a differentime when telephone line conditions have improved.
	Subsequent page transmission can still occur and later pages may be received without error.	If the error persists, select a lower speed for the initial transmission speed.
332–337	There is a defect in the sending fax product.	Send from another product.
338-342 (ECM error)		
343		
344–348	One of the following has occurred:	Reattempt the fax transmission at a different transmission at a different transmission.
349-353 (ECM error)	The sending product has failed to respond to a fax command from the receiving product	time when telephone line conditions have improved.
354 and 355	 due to the connection being interrupted. The sender has touched the Cancel X button while the reception was in progress. 	fax session was using error correction, disable ECM.
	 In rare conditions, incompatibility between the two products may cause the sending product to abandon the call. 	

Table 2-6 Fax send error codes (continued)

Error code	Description	Solution		
356-361 362-366 (ECM error)	One of the following has occurred: • The sender has touched the Cancel X button, causing the session to be aborted.	 Configure the sending product for document reception by clearing any paper jams, loading sufficient paper, and clearing any other system errors. 		
	 The sending product has encountered a system problem such as no paper or a paper jam, which has inhibited it from receiving any more pages, and which has caused it to terminate the session prematurely. A feature incompatibility has been encountered by the sending product, causing it to terminate the session. 	Configure the receiving fax product to use different configurations, toggle the ECM state, or select a slower reception speed.		
367-372	The sending product appears to be "stuck on".	N/A		
373-377 (ECM error)				
378 and 379				
380	The sending product has failed to issue a valid response to a CTC frame. This occurs during ECM transmission after multiple retransmissions of erred data.	Send from another product.		
381	 One of the following has occurred: The sending product has failed to respond to a fax command from the receiving product due to the connection being interrupted. The sender has touched the Cancel button while the reception was in progress. 	 Reattempt the fax transmission at a differentime when telephone line conditions have improved. If the error persists, disable ECM. 		
382	The sending fax product has been "holding off" the receiving fax product from continuing the ongoing transmission due to a temporary low memory condition at the sending product. If this "hold-off" period exceeds a product's specific timeout value, the session will terminate.	 Resend the document as two or more separate fax transmissions. Wait several minutes between the end of one transmission and the start of the next transmission. If the error persists, disable ECM. 		
383	 One of the following has occurred: The sending product has failed to respond to a fax command from the receiving product due to the connection being interrupted The sender has touched the Cancel x button while the reception was in progress. 	 Reattempt the fax transmission at a differentime when telephone line conditions have improved. If the error persists, disable ECM. 		
384	The receiving product has attempted a black JPEG transmission to a product that does not support this mode.	Reattempt the fax transmission using a different mode.		

Table 2-6 Fax send error codes (continued)

Error code	Description	Solution		
386	The receiving product has failed to complete the third phase of the initial V.34 handshake after originating a fax session. This is usually due to poor line conditions although it may be a compatibility issue with certain products and/or line conditions.	 Reattempt the fax transmission at a differentime when telephone line conditions have improved. Disable V.34 on the receiving product and attempt the transmission using the V.17 mode. 		
387	The receiving product has failed to successfully negotiate the initial V.8 handshake with the sending product after originating a fax session. Typically this will occur when the sending product is not fax capable or has disabled reception. It may also be a compatibility issue with certain products and/or line conditions.	mode.		
388	The receiving product has originated a fax session and detected a sending fax product but has been unable to detect any T30 frames. If the product is in V.17 mode it is likely that the connection has been interrupted. In V.34 mode is also possible for this error to occur due to compatibility problems with certain products and/ or line conditions.	-		
389	The receiving product has originated a fax session and has reattempted V.8 negotiations multiple times without success.	-		
390	The receiving product has originated a fax session using error correction (either V.34 or V. 17). Transmission of an image has been abandoned after a timeout when no data has become ready for transmission. This is most likely due to a low memory condition although it could be due to other internal problems that cause generation of data for transmission to stall.	Reattempt the transmission after making sure documents stored in memory are printed and the product has paper ready for printing. If the problem persists reinitialize permanent storage.		
391	The receiving product has originated a fax session without error correction (not V.34). Transmission of an image has been abandoned after a timeout when no data has become ready for transmission. This is most likely due to a low memory condition although it could be due to other internal problems that cause generation of data for transmission to stall.	-		

Table 2-6 Fax send error codes (continued)

Error code	Description	Solution	
392	The receiving product has answered a fax session and completed the initial V.34 handshake but has been to detect any T30 frames. This failure is either a compatibility problems with certain products or is due to line conditions.	2. I	Reattempt the fax reception at a different time when telephone line conditions have improved. Disable V.34 on the receiving product and
393	The receiving product has failed to complete the third phase of the initial V.34 handshake after answering a fax session. This is usually due to poor line conditions although it may be a compatibility issue with certain products and/or line conditions.		attempt the transmission using the V.17 mode.
394	The receiving product has failed to successfully negotiate the initial V.8 handshake with the sending product after answering a fax session. Typically this will occur when the calling product is not fax capable. It may also be a compatibility issue with certain products and/or line conditions.		
395	An unexpected T.30 frame has been received between pages during a multipage V.34 reception. This is almost certainly a compatibility problem with the sending product and may be due to an error with the implementation of the sending	(Reattempt the fax reception. If transmission errors are not encountered because line conditions have improved, then this error will probably be avoided.
	product.		Disable V.34 on the receiving product and attempt the transmission using the V.17 mode.

Table 2-6 Fax send error codes (continued)

Error code	Description	Solution
396–409	An error occurred during a V.34 transmission when the receiving product was unable to correctly handshake with the sending product and was consequently unable to transmit a T30 frame. This occurs when the line was disconnected or if line conditions degrade during the session.	Reattempt the fax transmission at a different time when telephone line conditions have improved.
410–419	An error occurred during a V.34 reception when the receiving product was unable to correctly handshake with the sending product and was consequently unable to transmit a T30 frame. This occurs when the line is disconnected or if line conditions degrade during the session.	
420	V.34 negotiations have failed from the originating product during phase four, which occurs after V.8 and before the first T.30 frames are exchanged. Compatibility problems have been observed in this area when sending to non-HP units.	
421	V.34 negotiations have failed from the originating product during phase three, which occurs after V. 8, before phase four, and before the first T.30 frames are exchanged. Compatibility problems have been observed in this area when sending to non-HP units.	
422	V.34 negotiations have failed from the answering product during phase four, which occurs after V.8 and before the first T.30 frames are exchanged.	-
423	V.34 negotiations have failed from the answering product during phase three, which occurs after V. 8, before phase4, and before the first T.30 frames are exchanged.	-
430	The transmitting product is unable to send continuous ones at the end of the control channel prior to starting the primary channel. This is a V. 34 error. This error may be associated with line conditions although it is more likely to be due to internal problems with the modem.	
431	The transmitting product has not received a response after aborting a transmission. Depending upon when the session is aborted, some sending products may not respond. It should be noted that the receiving unit always attempts to abort the session in a way that allows the sending product to respond to the final PPS_EOP.	N/A
440–445	An error occurred during a V.34 transmission after one or more partial pages (image data) were transmitted using the primary channel. The transmitting product was unable to restart the control channel in order to resume the T30 handshake. This typically occurs when the receiving product prematurely disconnects during partial page reception, although it is possible it may also be due to compatibility issues.	Reattempt the fax reception at a different time when telephone line conditions have improved.

Fax trace report

A fax T.30 trace report has information that can help resolve fax transmission problems. If you call HP for help in resolving these problems, print a T.30 trace report before you call.

- From the Home screen, touch the Setup \(\) button.
- Touch the Service menu.
- 3. Touch the Fax Service menu.
- 4. Touch the Print T.30 Trace button, and then touch the Now button.

Product updates

Software and firmware updates and installation instructions for this product are available at www.hp.com/support/CM1410series. Click **Downloads and drivers**, click the operating system, and then select the download for the product.

3 Parts and diagrams

- Order parts by authorized service providers
- How to use the parts lists and diagrams
- Assembly locations
- <u>Covers</u>
- Internal assemblies
- PCAs
- Scanner and document feeder (ADF) main assemblies
- Document feeder internal components
- Alphabetical parts list
- Numerical parts list

ENWW 157

Order parts by authorized service providers

Order replacement parts

Table 3-1 Order parts, accessories, and supplies

Order supplies and paper	www.hp.com/go/suresupply	
Order genuine HP parts or accessories	www.hp.com/buy/parts	
Order through service or support providers	Contact an HP-authorized service or support provider.	

Related documentation and software

Table 3-2 Related documentation and software

Item	Description	Part number
HP LaserJet Pro CM1410 Color MFP Series User Guide	Product user guide.	CE861-90907
HP LaserJet Pro CM1410 Color MFP Series Service Manual (this manual)	English service manual (this manual)	CE861-90939

Supplies part numbers

Table 3-3 Supplies part numbers

Table 5-5 Supplies part numbers			
Item	Description	Part number	
HP LaserJet print cartridges	Black	CE320A (new)	
		CE320-67901 (exchange)	
	Cyan	CE321A (new)	
		CE321-67902 (exchange)	
	Yellow	CE322A (new)	
		CE322-67901 (exchange)	
	Magenta	CE323A (new)	
		CE323-67901 (exchange)	

Service parts

NOTE: The parts in the following table are not shown in the assembly illustrations in this chapter.

Table 3-4 Service parts

Item	Description	Part number	
HP jewel	HP logo	7121-8266	

Customer self repair parts

Table 3-5 Customer replaceable units (CRU) kit part numbers

Item	Description	Part number
Document-feeder input tray	Instructions, install Document feeder (ADF) input tray	CE861-90973
Cassette	Instructions, install paper tray (cassette)	CE861-90974

Whole-unit replacement part numbers

NOTE: Whole-unit replacement products include the formatter PCA.

Table 3-6 Whole-unit replacement part numbers

Item	Descripti on	Part number
HP LaserJet Pro CM1415fn	110 V	CE861-67001 (North American Region, and Taiwan); New
		• CE861-67006 (Brasil); New
	220 V	CE861-69002 (Europe, Middle East, and Africa); Exchange
		CE861-67003 (China, and Malaysia); New
		CE861-67004 (Asian Pacific, and Latin America Region); New
		CE861-67005 (Chile, and Argentina); New
HP LaserJet Pro CM1415fnw	110 V	CE862-67001 (North American Region, and Taiwan); New
		• CE862-67006 (Brasil); New
	220 V	CE862-69002 (Europe, Middle East, and Africa); Exchange
		CE862-67003 (China, and Malaysia); New
		CE862-67004 (Asian Pacific, and Latin American Region); New
		CE862-67005 (Chile, and Argentina); New

How to use the parts lists and diagrams

- △ CAUTION: Be sure to order the correct part. When looking for part numbers for electrical components, pay careful attention to the voltage that is listed. Doing so will make sure that the part number selected is for the correct model.
- NOTE: In this manual, the abbreviation "PCA" stands for "printed circuit-board assembly."

 Components described as a PCA might consist of a single circuit board or a circuit board plus other parts, such as cables and sensors.

The figures in this chapter show the major subassemblies in the product and their component parts. A parts list table follows each exploded view assembly diagram. Each table lists the item number, the associated part number, and the description of each part. If a part is not listed in the table, then it is not a field replacement unit (FRU).

Assembly locations

Base product

Figure 3-1 Base product




Table 3-7 Base product

Item	Description	Item	Description
1	Document feeder input tray	7	Right-front cover-2
2	Document feeder output bin	8	Input tray (Tray 1)
3	Scanner lid	9	Front door
4	Color touch screen control panel	10	Output bin
5	Right cover	11	Top cover
6	Right-front cover-1	12	Left cover

ENWW Assembly locations 161

Covers

Figure 3-2 Covers, panels, and doors




Table 3-8 Covers, panels, and doors

Ref	Description	Part number	Qty
1	Cover, left	RC1-0795-000CN	1
2	Cover, rear upper	RC3-0819-000CN	1
3	Cover, rear lower	RC3-0753-000CN	1
4	Cover, rear center	RC3-0767-000CN	1
5	Door, front	RC3-0796-000CN	1
6	Cover, top assembly	RM1-7715-000CN	1
7	Cover, priority slot (jam access)	RM3-0812-000CN	1
8	Cover, right	RC3-0794-000CN	1
9	Door, rear	RC3-0820-000CN	1
10	Cover, right-front 1	RC3-0797-000CN	1
11	Cover, right-front 2	RC3-0798-000CN	1

ENWW Covers 163

Internal assemblies

Internal assemblies (1 of 4)

Figure 3-3 Internal assemblies (1 of 4)




Table 3-9 Internal assemblies (1 of 4)

Ref	Description	Part number	Qty
1	Separation roller assembly	RM1-4425-000CN	1
2	Pickup roller assembly	RM1-4426-000CN	1
5	Cassette assembly	RM1-7714-000CN	1
7	Cover, holder	RC2-2014-000CN	1

ENWW Internal assemblies 165

Internal assemblies (2 of 4)

*A19 *A18 *A02 *A12 *A15 (J701) 😚 (J121) 🕥 *A18 *A13 (SR603) (J603) *A18 (J202) *A\05 (J11) (J102) *A01 *A18 *A\07 *À18 *A06

*A\09

*A¹8

Figure 3-4 Internal assemblies (2 of 4)

Table 3-10 Internal assemblies (2 of 4)

Ref	Description	Part number	Qty
3	DC controller assembly	RM1-7813-000CN	1
4	Low-voltage power supply (110 to 127 v)	RM1-7830-000CN	1
4	Low-voltage power supply (220 to 240 v)	RM1-7831-000CN	1
6	Motor, DC main	RL1-1834-000CN	1
7	Cable, flat (FFC)	RK2-1955-000CN	1

ENWW Internal assemblies 167

Internal assemblies (3 of 4)

Figure 3-5 Internal assemblies (3 of 4)




Table 3-11 Internal assemblies (3 of 4)

Ref	Description	Part number	Qty
3	High-voltage power supply	RM1-7090-000CN	1
4	Intermediate transfer belt (ITB) assembly	RM1-7866-000CN	1
5	Bushing (transfer roller)	RC2-2111-000CN	1
6	Bushing (transfer roller)	RC2-2112-000CN	1
7	Roller, transfer	RM1-4445-000CN	1
8	Paper feed guide assembly	RM1-4448-000CN	1

ENWW Internal assemblies 169

Internal assemblies (4 of 4)

*A17_ (J703) *A23 *A17 *A18 *A24 (J802) *A,17 (J110) *A25 *A17 (J607) (J104) 'A11 *A17 A07 *A10 (J118) *A05 *A19 *A17 -*A15 *A13 *A04 *A[']14 *A06 *A08 *A16 *A30 *A02 *A17 `@*À29 *A\17 *A19 *A28 *A\17 *A20 *A\01

Figure 3-6 Internal assemblies (4 of 4)

Table 3-12 Internal assemblies (4 of 4)

Ref	Description	Part number	Qty
1	Fuser assembly (110 to 127 v)	RM1-4430-000CN	1
1	Fuser assembly (220 to 240 v)	RM1-4431-000CN	1
2	Fuser drive assembly	RM1-4927-000CN	1
3	Cartridge tray assembly	RM1-7853-000CN	1
4	Motor, stepping DC fuser	RK2-1872-000CN	1

ENWW Internal assemblies 171

PCAs

Figure 3-7 PCAs




Table 3-13 PCAs

Ref	Description	Part number	Qty
1	High-voltage power supply	RM1-7090-000CN	1
2	Fuser power supply (110 to 127 v)	RM1-7082-000CN	1
2	Fuser power supply (220 to 240 v)	RM1-7083-000CN	1
3	Low-voltage power supply (110 to 127 v)	RM1-7830-000CN	1
3	Low-voltage power supply (220 to 240 v)	RM1-7831-000CN	1
4	Fax PCA, DAA EU	CE683-67901	1
4	Fax PCA, DAA AA	CE682-67901	1
5	Formatter PCA	CE690-67901	1
6	DC controller assembly	RM1-7813-000CN	1
Not shown	Wireless PCA	1150-7938	1
Not shown	USB PCA	CF030-67901	1

ENWW PCAs 173

Scanner and document feeder (ADF) main assemblies

Figure 3-8 Scanner and document feeder main assemblies




Table 3-14 Scanner and document feeder main assemblies

Ref	Description	Part number	Qty
1	Document feeder (ADF) motor cover	CE538-40015	1
2	Document feeder (ADF) assembly	CE538-60121	1
4	Scanner assembly	CE861-60110	1
5	Control-panel PCA assembly	CE862-60101	1

Document feeder internal components

To the state of th

Figure 3-9 Document feeder assembly parts

Table 3-15 Document feeder assembly parts

Ref	Description	Part number	Qty
1	Document feeder (ADF) core assembly	CE538-60122	1
2	Document feeder (ADF) input tray	CE538-60127	1
3	Document feeder (ADF) base	CE538-60126	1
4	Document feeder (ADF) cover, outer	CE538-40009	1
5	Document feeder (ADF) pick arm assembly	CE538-60137	1
6	Spring, document feeder (ADF) extension (pre-pick)	Q7400-00011	1
8	Shaft, document feeder (ADF) pick extension	Q7400-40047	1
9	Document feeder (ADF) cover, inner	CE538-40008	1
10	Roller assembly, document feeder (ADF) post-scan pinch	Q7400-60153	2
11	Document feeder (ADF) separation pad assembly	Q7400-60159	1

Alphabetical parts list

Table 3-16 Alphabetical parts list

Description	Part number	Table and page
Bushing (transfer roller)	RC2-2111-000CN	Internal assemblies (3 of 4) on page 169
Bushing (transfer roller)	RC2-2112-000CN	Internal assemblies (3 of 4) on page 169
Cable, flat (FFC)	RK2-1955-000CN	Internal assemblies (2 of 4) on page 167
Cartridge tray assembly	RM1-7853-000CN	Internal assemblies (4 of 4) on page 171
Cassette assembly	RM1-7714-000CN	Internal assemblies (1 of 4) on page 165
Control-panel PCA assembly	CE862-60101	Scanner and document feede main assemblies on page 175
Cover, holder	RC2-2014-000CN	Internal assemblies (1 of 4) on page 165
Cover, left	RC1-0795-000CN	Covers, panels, and doors on page 163
Cover, priority slot (jam access)	RM3-0812-000CN	Covers, panels, and doors on page 163
Cover, rear center	RC3-0767-000CN	Covers, panels, and doors on page 163
Cover, rear lower	RC3-0753-000CN	Covers, panels, and doors on page 163
Cover, rear upper	RC3-0819-000CN	Covers, panels, and doors on page 163
Cover, right	RC3-0794-000CN	Covers, panels, and doors on page 163
Cover, right-front 1	RC3-0797-000CN	Covers, panels, and doors on page 163
Cover, right-front 2	RC3-0798-000CN	Covers, panels, and doors on page 163
Cover, top assembly	RM1-7715-000CN	Covers, panels, and doors on page 163
DC controller assembly	RM1-7813-000CN	Internal assemblies (2 of 4) on page 167
DC controller assembly	RM1-7813-000CN	PCAs on page 173
Document feeder (ADF) assembly	CE538-60121	Scanner and document feede main assemblies on page 175
Document feeder (ADF) base	CE538-60126	Document feeder assembly parts on page 177
Document feeder (ADF) core assembly	CE538-60122	Document feeder assembly parts on page 177

Table 3-16 Alphabetical parts list (continued)

Description	Part number	Table and page
Document feeder (ADF) cover, inner	CE538-40008	Document feeder assembly parts on page 177
Document feeder (ADF) cover, outer	CE538-40009	Document feeder assembly parts on page 177
Document feeder (ADF) input tray	CE538-60127	Document feeder assembly parts on page 177
Document feeder (ADF) motor cover	CE538-40015	Scanner and document feede main assemblies on page 175
Document feeder (ADF) pick arm assembly	CE538-60137	Document feeder assembly parts on page 177
Document feeder (ADF) separation pad assembly	Q7400-60159	Document feeder assembly parts on page 177
Door, front	RC3-0796-000CN	Covers, panels, and doors on page 163
Door, rear	RC3-0820-000CN	Covers, panels, and doors on page 163
Fax PCA, DAA AA	CE682-67901	PCAs on page 173
Fax PCA, DAA EU	CE683-67901	PCAs on page 173
Formatter PCA	CE690-67901	PCAs on page 173
Fuser assembly (110 to 127 v)	RM1-4430-000CN	Internal assemblies (4 of 4) on page 171
Fuser assembly (220 to 240 v)	RM1-4431-000CN	Internal assemblies (4 of 4) on page 171
Fuser drive assembly	RM1-4927-000CN	Internal assemblies (4 of 4) on page 171
Fuser power supply (110 to 127 v)	RM1-7082-000CN	PCAs on page 173
Fuser power supply (220 to 240 v)	RM1-7083-000CN	PCAs on page 173
High-voltage power supply	RM1-7090-000CN	Internal assemblies (3 of 4) on page 169
High-voltage power supply	RM1-7090-000CN	PCAs on page 173
Intermediate transfer belt (ITB) assembly	RM1-7866-000CN	Internal assemblies (3 of 4) on page 169
Low-voltage power supply (110 to 127 v)	RM1-7830-000CN	Internal assemblies (2 of 4) on page 167
Low-voltage power supply (110 to 127 v)	RM1-7830-000CN	PCAs on page 173
Low-voltage power supply (220 to 240 v)	RM1-7831-000CN	Internal assemblies (2 of 4) on page 167
Low-voltage power supply (220 to 240 v)	RM1-7831-000CN	PCAs on page 173
Motor, DC main	RL1-1834-000CN	Internal assemblies (2 of 4) on page 167
Motor, stepping DC fuser	RK2-1872-000CN	Internal assemblies (4 of 4) on page 171

ENWW Alphabetical parts list 179

Table 3-16 Alphabetical parts list (continued)

Description	Part number	Table and page
Paper feed guide assembly	RM1-4448-000CN	Internal assemblies (3 of 4) on page 169
Pickup roller assembly	RM1-4426-000CN	Internal assemblies (1 of 4) on page 165
Roller assembly, document feeder (ADF) post-scan pinch	Q7400-60153	Document feeder assembly parts on page 177
Roller, transfer	RM1-4445-000CN	Internal assemblies (3 of 4) on page 169
Scanner assembly	CE861-60110	Scanner and document feeder main assemblies on page 175
Separation roller assembly	RM1-4425-000CN	Internal assemblies (1 of 4) on page 165
Shaft, document feeder (ADF) pick extension	Q7400-40047	Document feeder assembly parts on page 177
Spring, document feeder (ADF) extension (pre-pick)	Q7400-00011	Document feeder assembly parts on page 177
USB PCA	CF030-67901	PCAs on page 173
Wireless PCA	1150-7938	PCAs on page 173

Numerical parts list

Table 3-17 Numerical parts list

Part number	Description	Table and page
1150-7938	Wireless PCA	PCAs on page 173
CE538-40008	Document feeder (ADF) cover, inner	Document feeder assembly parts on page 177
CE538-40009	Document feeder (ADF) cover, outer	Document feeder assembly parts on page 177
CE538-40015	Document feeder (ADF) motor cover	Scanner and document feeder main assemblies on page 175
CE538-60121	Document feeder (ADF) assembly	Scanner and document feeder main assemblies on page 175
CE538-60122	Document feeder (ADF) core assembly	Document feeder assembly parts on page 177
CE538-60126	Document feeder (ADF) base	Document feeder assembly parts on page 177
CE538-60127	Document feeder (ADF) input tray	Document feeder assembly parts on page 177
CE538-60137	Document feeder (ADF) pick arm assembly	Document feeder assembly parts on page 177
CE682-67901	Fax PCA, DAA AA	PCAs on page 173
CE683-67901	Fax PCA, DAA EU	PCAs on page 173
CE690-67901	Formatter PCA	PCAs on page 173
CE861-60110	Scanner assembly	Scanner and document feeder main assemblies on page 175
CE862-60101	Control-panel PCA assembly	Scanner and document feeder main assemblies on page 175
CF030-67901	USB PCA	PCAs on page 173
Q7400-00011	Spring, document feeder (ADF) extension (pre-pick)	Document feeder assembly parts on page 177
Q7400-40047	Shaft, document feeder (ADF) pick extension	Document feeder assembly parts on page 177
Q7400-60153	Roller assembly, document feeder (ADF) post-scan pinch	Document feeder assembly parts on page 177
Q7400-60159	Document feeder (ADF) separation pad assembly	Document feeder assembly parts on page 177
RC1-0795-000CN	Cover, left	Covers, panels, and doors on page 163
RC2-2014-000CN	Cover, holder	Internal assemblies (1 of 4) on page 165
RC2-2111-000CN	Bushing (transfer roller)	Internal assemblies (3 of 4) on page 169

ENWW Numerical parts list 181

Table 3-17 Numerical parts list (continued)

Part number	Description	Table and page
RC2-2112-000CN	Bushing (transfer roller)	Internal assemblies (3 of 4) on page 169
RC3-0753-000CN	Cover, rear lower	Covers, panels, and doors on page 163
RC3-0767-000CN	Cover, rear center	Covers, panels, and doors on page 163
RC3-0794-000CN	Cover, right	Covers, panels, and doors on page 163
RC3-0796-000CN	Door, front	Covers, panels, and doors on page 163
RC3-0797-000CN	Cover, right-front 1	Covers, panels, and doors on page 163
RC3-0798-000CN	Cover, right-front 2	Covers, panels, and doors on page 163
RC3-0819-000CN	Cover, rear upper	Covers, panels, and doors on page 163
RC3-0820-000CN	Door, rear	Covers, panels, and doors on page 163
RK2-1872-000CN	Motor, stepping DC fuser	Internal assemblies (4 of 4) on page 171
RK2-1955-000CN	Cable, flat (FFC)	Internal assemblies (2 of 4) on page 167
RL1-1834-000CN	Motor, DC main	Internal assemblies (2 of 4) on page 167
RM1-4425-000CN	Separation roller assembly	Internal assemblies (1 of 4) on page 165
RM1-4426-000CN	Pickup roller assembly	Internal assemblies (1 of 4) on page 165
RM1-4430-000CN	Fuser assembly (110 to 127 v)	Internal assemblies (4 of 4) on page 171
RM1-4431-000CN	Fuser assembly (220 to 240 v)	Internal assemblies (4 of 4) on page 171
RM1-4445-000CN	Roller, transfer	Internal assemblies (3 of 4) on page 169
RM1-4448-000CN	Paper feed guide assembly	Internal assemblies (3 of 4) on page 169
RM1-4927-000CN	Fuser drive assembly	Internal assemblies (4 of 4) on page 171
RM1-7082-000CN	Fuser power supply (110 to 127 v)	PCAs on page 173
RM1-7083-000CN	Fuser power supply (220 to 240 v)	PCAs on page 173
RM1-7090-000CN	High-voltage power supply	Internal assemblies (3 of 4) on page 169
RM1-7090-000CN	High-voltage power supply	PCAs on page 173

Table 3-17 Numerical parts list (continued)

Part number	Description	Table and page
RM1-7714-000CN	Cassette assembly	Internal assemblies (1 of 4) on page 165
RM1-7715-000CN	Cover, top assembly	Covers, panels, and doors on page 163
RM1-7813-000CN	DC controller assembly	Internal assemblies (2 of 4) on page 167
RM1-7813-000CN	DC controller assembly	PCAs on page 173
RM1-7830-000CN	Low-voltage power supply (110 to 127 v)	Internal assemblies (2 of 4) on page 167
RM1-7830-000CN	Low-voltage power supply (110 to 127 v)	PCAs on page 173
RM1-7831-000CN	Low-voltage power supply (220 to 240 v)	Internal assemblies (2 of 4) on page 167
RM1-7831-000CN	Low-voltage power supply (220 to 240 v)	PCAs on page 173
RM1-7853-000CN	Cartridge tray assembly	Internal assemblies (4 of 4) on page 171
RM1-7866-000CN	Intermediate transfer belt (ITB) assembly	Internal assemblies (3 of 4) on page 169
RM3-0812-000CN	Cover, priority slot (jam access)	Covers, panels, and doors on page 163

ENWW Numerical parts list 183

A Service and support

- Hewlett-Packard limited warranty statement
- HP's Premium Protection Warranty: LaserJet print cartridge limited warranty statement
- Data stored on the print cartridge
- End User License Agreement
- OpenSSL
- Customer support
- Repack the product

ENWW 185

Hewlett-Packard limited warranty statement

HP PRODUCT	DURATION OF LIMITED WARRANTY
HP LaserJet Pro CM1410 Color MFP Series	One year from date of purchase

HP warrants to you, the end-user customer, that HP hardware and accessories will be free from defects in materials and workmanship after the date of purchase, for the period specified above. If HP receives notice of such defects during the warranty period, HP will, at its option, either repair or replace products which prove to be defective. Replacement products may be either new or equivalent in performance to new.

HP warrants to you that HP software will not fail to execute its programming instructions after the date of purchase, for the period specified above, due to defects in material and workmanship when properly installed and used. If HP receives notice of such defects during the warranty period, HP will replace software which does not execute its programming instructions due to such defects.

HP does not warrant that the operation of HP products will be uninterrupted or error free. If HP is unable, within a reasonable time, to repair or replace any product to a condition as warranted, you will be entitled to a refund of the purchase price upon prompt return of the product.

HP products may contain remanufactured parts equivalent to new in performance or may have been subject to incidental use.

Warranty does not apply to defects resulting from (a) improper or inadequate maintenance or calibration, (b) software, interfacing, parts or supplies not supplied by HP, (c) unauthorized modification or misuse, (d) operation outside of the published environmental specifications for the product, or (e) improper site preparation or maintenance.

TO THE EXTENT ALLOWED BY LOCAL LAW, THE ABOVE WARRANTIES ARE EXCLUSIVE AND NO OTHER WARRANTY OR CONDITION, WHETHER WRITTEN OR ORAL, IS EXPRESSED OR IMPLIED AND HP SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, SATISFACTORY QUALITY, AND FITNESS FOR A PARTICULAR PURPOSE. Some countries/regions, states or provinces do not allow limitations on the duration of an implied warranty, so the above limitation or exclusion might not apply to you. This warranty gives you specific legal rights and you might also have other rights that vary from country/region to country/region, state to state, or province to province.

HP's limited warranty is valid in any country/region or locality where HP has a support presence for this product and where HP has marketed this product. The level of warranty service you receive may vary according to local standards. HP will not alter form, fit or function of the product to make it operate in a country/region for which it was never intended to function for legal or regulatory reasons.

TO THE EXTENT ALLOWED BY LOCAL LAW, THE REMEDIES IN THIS WARRANTY STATEMENT ARE YOUR SOLE AND EXCLUSIVE REMEDIES. EXCEPT AS INDICATED ABOVE, IN NO EVENT WILL HP OR ITS SUPPLIERS BE LIABLE FOR LOSS OF DATA OR FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFIT OR DATA), OR OTHER DAMAGE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE. Some countries/regions, states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

THE WARRANTY TERMS CONTAINED IN THIS STATEMENT, EXCEPT TO THE EXTENT LAWFULLY PERMITTED, DO NOT EXCLUDE, RESTRICT OR MODIFY AND ARE IN ADDITION TO THE MANDATORY STATUTORY RIGHTS APPLICABLE TO THE SALE OF THIS PRODUCT TO YOU.

HP's Premium Protection Warranty: LaserJet print cartridge limited warranty statement

This HP product is warranted to be free from defects in materials and workmanship.

This warranty does not apply to products that (a) have been refilled, refurbished, remanufactured or tampered with in any way, (b) experience problems resulting from misuse, improper storage, or operation outside of the published environmental specifications for the printer product or (c) exhibit wear from ordinary use.

To obtain warranty service, please return the product to place of purchase (with a written description of the problem and print samples) or contact HP customer support. At HP's option, HP will either replace products that prove to be defective or refund your purchase price.

TO THE EXTENT ALLOWED BY LOCAL LAW, THE ABOVE WARRANTY IS EXCLUSIVE AND NO OTHER WARRANTY OR CONDITION. WHETHER WRITTEN OR ORAL. IS EXPRESSED OR IMPLIED AND HP SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, SATISFACTORY QUALITY, AND FITNESS FOR A PARTICULAR PURPOSE.

TO THE EXTENT ALLOWED BY LOCAL LAW, IN NO EVENT WILL HP OR ITS SUPPLIERS BE LIABLE FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFIT OR DATA), OR OTHER DAMAGE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE.

THE WARRANTY TERMS CONTAINED IN THIS STATEMENT. EXCEPT TO THE EXTENT LAWFULLY PERMITTED, DO NOT EXCLUDE, RESTRICT OR MODIFY AND ARE IN ADDITION TO THE MANDATORY STATUTORY RIGHTS APPLICABLE TO THE SALE OF THIS PRODUCT TO YOU.

Data stored on the print cartridge

The HP print cartridges used with this product contain a memory chip that assists in the operation of the product.

In addition, this memory chip collects a limited set of information about the usage of the product, which might include the following: the date when the print cartridge was first installed, the date when the print cartridge was last used, the number of pages printed using the print cartridge, the page coverage, the printing modes used, any printing errors that might have occurred, and the product model. This information helps HP design future products to meet our customers' printing needs.

The data collected from the print cartridge memory chip does not contain information that can be used to identify a customer or user of the print cartridge or their product.

HP collects a sampling of the memory chips from print cartridges returned to HP's free return and recycling program (HP Planet Partners: www.hp.com/recycle). The memory chips from this sampling are read and studied in order to improve future HP products. HP partners who assist in recycling this print cartridge might have access to this data, as well.

Any third party possessing the print cartridge might have access to the anonymous information on the memory chip. If you prefer to not allow access to this information, you can render the chip inoperable. However, after you render the memory chip inoperable, the memory chip cannot be used in an HP product.

End User License Agreement

PLEASE READ CAREFULLY BEFORE USING THIS SOFTWARE PRODUCT: This End-User License Agreement ("EULA") is a contract between (a) you (either an individual or the entity you represent) and (b) Hewlett-Packard Company ("HP") that governs your use of the software product ("Software"). This EULA does not apply if there is a separate license agreement between you and HP or its suppliers for the Software, including a license agreement in online documentation. The term "Software" may include (i) associated media, (ii) a user guide and other printed materials, and (iii) "online" or electronic documentation (collectively "User Documentation").

RIGHTS IN THE SOFTWARE ARE OFFERED ONLY ON THE CONDITION THAT YOU AGREE TO ALL TERMS AND CONDITIONS OF THIS EULA. BY INSTALLING, COPYING, DOWNLOADING, OR OTHERWISE USING THE SOFTWARE, YOU AGREE TO BE BOUND BY THIS EULA. IF YOU DO NOT ACCEPT THIS EULA, DO NOT INSTALL, DOWNLOAD, OR OTHERWISE USE THE SOFTWARE. IF YOU PURCHASED THE SOFTWARE BUT DO NOT AGREE TO THIS EULA, PLEASE RETURN THE SOFTWARE TO YOUR PLACE OF PURCHASE WITHIN FOURTEEN DAYS FOR A REFUND OF THE PURCHASE PRICE; IF THE SOFTWARE IS INSTALLED ON OR MADE AVAILABLE WITH ANOTHER HP PRODUCT, YOU MAY RETURN THE ENTIRE UNUSED PRODUCT.

- 1. THIRD PARTY SOFTWARE. The Software may include, in addition to HP proprietary software ("HP Software"), software under licenses from third parties ("Third Party Software" and "Third Party License"). Any Third Party Software is licensed to you subject to the terms and conditions of the corresponding Third Party License. Generally, the Third Party License is located in a file such as license.txt; you should contact HP support if you cannot find any Third Party License. If the Third Party Licenses include licenses that provide for the availability of source code (such as the GNU General Public License) and the corresponding source code is not included with the Software, then check the product support pages of HP's website (hp.com) to learn how to obtain such source code.
- 2. LICENSE RIGHTS. You will have the following rights provided you comply with all terms and conditions of this EULA:
- a. Use. HP grants you a license to Use one copy of the HP Software. "Use" means installing, copying, storing, loading, executing, displaying, or otherwise using the HP Software. You may not modify the HP Software or disable any licensing or control feature of the HP Software. If this Software is provided by HP for Use with an imaging or printing product (for example, if the Software is a printer driver, firmware, or add-on), the HP Software may only be used with such product ("HP Product"). Additional restrictions on Use may appear in the User Documentation. You may not separate component parts of the HP Software for Use. You do not have the right to distribute the HP Software.
- b. Copying. Your right to copy means you may make archival or back-up copies of the HP Software, provided each copy contains all the original HP Software's proprietary notices and is used only for back-up purposes.
- 3. UPGRADES. To Use HP Software provided by HP as an upgrade, update, or supplement (collectively "Upgrade"), you must first be licensed for the original HP Software identified by HP as eligible for the Upgrade. To the extent the Upgrade supersedes the original HP Software, you may no longer use such HP Software. This EULA applies to each Upgrade unless HP provides other terms with the Upgrade. In case of a conflict between this EULA and such other terms, the other terms will prevail.

4. TRANSFER.

a. Third Party Transfer. The initial end user of the HP Software may make a one-time transfer of the HP Software to another end user. Any transfer will include all component parts, media, User Documentation, this EULA, and if applicable, the Certificate of Authenticity. The transfer may not be

- an indirect transfer, such as a consignment. Prior to the transfer, the end user receiving the transferred Software will agree to this EULA. Upon transfer of the HP Software, your license is automatically terminated.
- b. Restrictions. You may not rent, lease or lend the HP Software or Use the HP Software for commercial timesharing or bureau use. You may not sublicense, assign or otherwise transfer the HP Software except as expressly provided in this EULA.
- 5. PROPRIETARY RIGHTS. All intellectual property rights in the Software and User Documentation. are owned by HP or its suppliers and are protected by law, including applicable copyright, trade secret, patent, and trademark laws. You will not remove any product identification, copyright notice, or proprietary restriction from the Software.
- 6. LIMITATION ON REVERSE ENGINEERING. You may not reverse engineer, decompile, or disassemble the HP Software, except and only to the extent that the right to do so is allowed under applicable law.
- 7. CONSENT TO USE OF DATA. HP and its affiliates may collect and use technical information you provide in relation to (i) your Use of the Software or the HP Product, or (ii) the provision of support services related to the Software or the HP Product. All such information will be subject to HP's privacy policy. HP will not use such information in a form that personally identifies you except to the extent necessary to enhance your Use or provide support services.
- 8. LIMITATION OF LIABILITY. Notwithstanding any damages that you might incur, the entire liability of HP and its suppliers under this EULA and your exclusive remedy under this EULA will be limited to the greater of the amount actually paid by you for the Product or U.S. \$5.00. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL HP OR ITS SUPPLIERS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOST PROFITS, LOST DATA, BUSINESS INTERRUPTION, PERSONAL INJURY. OR LOSS OF PRIVACY) RELATED IN ANY WAY TO THE USE OF OR INABILITY TO USE THE SOFTWARE, EVEN IF HP OR ANY SUPPLIER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND EVEN IF THE ABOVE REMEDY FAILS OF ITS ESSENTIAL PURPOSE. Some states or other jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.
- 9. U.S. GOVERNMENT CUSTOMERS. If you are a U.S. Government entity, then consistent with FAR 12.211 and FAR 12.212, Commercial Computer Software, Computer Software Documentation, and Technical Data for Commercial Items are licensed under the applicable HP commercial license agreement.
- 10. COMPLIANCE WITH EXPORT LAWS. You will comply with all laws, rules, and regulations (i) applicable to the export or import of the Software, or (ii) restricting the Use of the Software, including any restrictions on nuclear, chemical, or biological weapons proliferation.
- 11. RESERVATION OF RIGHTS. HP and its suppliers reserve all rights not expressly granted to you in this EULA.
- (c) 2007 Hewlett-Packard Development Company, L.P.

Rev. 11/06

OpenSSL

This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (http://www.openssl.org/)

THIS SOFTWARE IS PROVIDED BY THE OPENSSL PROJECT ``AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OPENSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES;

LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com). This product includes software written by Tim Hudson (tjh@cryptsoft.com).

Customer support

Get telephone support for your country/region	Country/region phone numbers are on the flyer that was in the box with your product or at www.hp.com/support/ .	
Have the product name, serial number, date of purchase, and problem description ready.		
Get 24-hour Internet support	www.hp.com/support/CM1410series	
Get support for products used with a Macintosh computer	www.hp.com/go/macosx	
Download software utilities, drivers, and electronic information	www.hp.com/support/CM1410series	
Order additional HP service or maintenance agreements	www.hp.com/go/carepack	
Register your product	www.register.hp.com	

ENWW OpenSSL 191

Repack the product

If HP Customer Care determines that your product needs to be returned to HP for repair, follow these steps to repack the product before shipping it.

- △ CAUTION: Shipping damage as a result of inadequate packing is the customer's responsibility.
 - 1. Remove and retain the print cartridges.
 - △ CAUTION: It is *extremely important* to remove the print cartridges before shipping the product. A print cartridge that remains in the product during shipping can leak and cover the product engine and other parts with toner.

To prevent damage to the print cartridges, avoid touching the rollers on them, and store the print cartridges so that they are not exposed to light.

- 2. Remove and retain the power cable, interface cable, and any optional accessories.
- 3. If possible, include print samples and 50 to 100 sheets of paper that did not print correctly.
- 4. In the U.S., call HP Customer Care to request new packing material. In other areas, use the original packing material, if possible.

B Product specifications

- Physical specifications
- Power consumption, electrical specifications, and acoustic emissions
- Environmental specifications

ENWW 193

Physical specifications

Table B-1 Physical specifications

Product	Height	Depth	Width	Weight
HP LaserJet Pro CM1415	413 mm (16.3 inches)	472 mm (18.6 inches)	442 mm (17.4 inches)	22.6 kg (49.8 lb)

Power consumption, electrical specifications, and acoustic emissions

See www.hp.com/support/CM1410series for current information.

△ CAUTION: Power requirements are based on the country/region where the product is sold. Do not convert operating voltages. This will damage the product and void the product warranty.

Environmental specifications

Table B-2 Environmental specifications¹

	Recommended	Operating	Storage
Temperature	15° to 32.5° C	15° to 32.5° C	–20° to 40° C
	(59° to 90.5° F)	(59° to 90.5° F)	(–4° to 104° F)
Relative humidity	20 to 70%	10 to 80%	95% or less
Altitude		0 to 3048 m (0 to 10,00	0 ft)

Values are subject to change.

C Regulatory information

- FCC regulations
- Environmental product stewardship program
- Declaration of Conformity
- Declaration of Conformity (wireless models)
- Certificate of Volatility
- Safety statements
- Additional statements for telecom (fax) products
- Additional statements for wireless products

ENWW 195

FCC regulations

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If this equipment is not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase separation between equipment and receiver.
- Connect equipment to an outlet on a circuit different from that to which the receiver is located.
- Consult your dealer or an experienced radio/TV technician.
- NOTE: Any changes or modifications to the printer that are not expressly approved by HP could void the user's authority to operate this equipment.

Use of a shielded interface cable is required to comply with the Class B limits of Part 15 of FCC rules.

Environmental product stewardship program

Protecting the environment

Hewlett-Packard Company is committed to providing quality products in an environmentally sound manner. This product has been designed with several attributes to minimize impacts on our environment.

Ozone production

This product generates no appreciable ozone gas (O₃).

Power consumption

Power usage drops significantly while in Ready or Sleep mode, which saves natural resources and saves money without affecting the high performance of this product. Hewlett-Packard printing and imaging equipment marked with the ENERGY STAR® logo is qualified to the U.S. Environmental Protection Agency's ENERGY STAR specifications for imaging equipment. The following mark will appear on ENERGY STAR qualified imaging products:



Additional ENERGY STAR qualified imaging product model information is listed at:

www.hp.com/go/energystar

Paper use

This product's manual duplex feature (two-sided printing) and N-up printing (multiple pages printed on one page) capability can reduce paper usage and the resulting demands on natural resources.

Plastics

Plastic parts over 25 grams are marked according to international standards that enhance the ability to identify plastics for recycling purposes at the end of the product's life.

HP LaserJet print supplies

It's easy to return and recycle your HP LaserJet print cartridges after use—free of charge—with HP Planet Partners. Multilingual program information and instructions are included in every new HP LaserJet print cartridge and supplies package. You help reduce the toll on the environment further when you return multiple cartridges together rather than separately.

HP is committed to providing inventive, high-quality products and services that are environmentally sound, from product design and manufacturing to distribution, customer use and recycling. When you participate in the HP Planet Partners program, we ensure your HP LaserJet print cartridges are recycled properly, processing them to recover plastics and metals for new products and diverting millions of tons of waste from landfills. Since this cartridge is being recycled and used in new materials, it will not be returned to you. Thank you for being environmentally responsible!

NOTE: Use the return label to return original HP LaserJet print cartridges only. Please do not use this label for HP inkjet cartridges, non-HP cartridges, refilled or remanufactured cartridges or warranty returns. For information about recycling your HP inkjet cartridges please go to http://www.hp.com/recycle.

Return and recycling instructions

United States and Puerto Rico

The enclosed label in the HP LaserJet toner cartridge box is for the return and recycling of one or more HP LaserJet print cartridges after use. Please follow the applicable instructions below.

Multiple returns (more than one cartridge)

- 1. Package each HP LaserJet print cartridge in its original box and bag.
- Tape the boxes together using strapping or packaging tape. The package can weigh up to 31 kg (70 lb).
- Use a single pre-paid shipping label.

OR

- 1. Use your own suitable box, or request a free bulk collection box from www.hp.com/recycle or 1-800-340-2445 (holds up to 31 kg (70 lb) of HP LaserJet print cartridges).
- 2. Use a single pre-paid shipping label.

Single returns

- 1. Package the HP LaserJet print cartridge in its original bag and box.
- 2. Place the shipping label on the front of the box.

Shipping

For all HP LaserJet print cartridge recycling returns, give the package to UPS during your next delivery or pickup, or take it to an authorized UPS drop-off center. For the location of your local UPS drop-off center, call 1-800-PICKUPS or visit www.ups.com. If you are returning via USPS label, give the package to a U.S. Postal Service carrier or drop off at a U.S. Postal Service Office. For more information, or to order additional labels or boxes for bulk returns, visit www.hp.com/recycle or call 1-800-340-2445. Requested UPS pickup will be charged normal pickup rates. Information subject to change without notice.

Residents of Alaska and Hawaii

Do not use the UPS label. Call 1-800-340-2445 for information and instructions. The U.S. Postal Service provides no-cost cartridge return transportation services under an arrangement with HP for Alaska and Hawaii.

Non-U.S. returns

To participate in HP Planet Partners return and recycling program, just follow the simple directions in the recycling guide (found inside the packaging of your new product supply item) or visit www.hp.com/recycle. Select your country/region for information on how to return your HP LaserJet printing supplies.

Paper

This product is capable of using recycled papers when the paper meets the guidelines outlined in the HP LaserJet Printer Family Print Media Guide. This product is suitable for the use of recycled paper according to EN12281:2002.

Material restrictions

This HP product does not contain added mercury.

This HP product contains a battery that might require special handling at end-of-life. The batteries contained in or supplied by Hewlett-Packard for this product include the following:

HP LaserJet Pro CM1410 Color MFP Series				
Туре	Carbon monofluoride lithium			
Weight	0.8 g			
Location	On formatter board			
User-removable	No			



廢電池請回收

For recycling information, you can go to www.hp.com/recycle, or contact your local authorities or the Electronics Industries Alliance: www.eiae.org.

Disposal of waste equipment by users in private households in the **European Union**



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Chemical substances

HP is committed to providing our customers with information about the chemical substances in our products as needed to comply with legal requirements such as REACH (Regulation EC No

1907/2006 of the European Parliament and the Council). A chemical information report for this product can be found at: www.hp.com/go/reach.

Material Safety Data Sheet (MSDS)

Material Safety Data Sheets (MSDS) for supplies containing chemical substances (for example, toner) can be obtained by accessing the HP Web site at www.hp.com/go/msds or <a href=

For more information

To obtain information about these environmental topics:

- Product environmental profile sheet for this and many related HP products
- HP's commitment to the environment
- HP's environmental management system
- HP's end-of-life product return and recycling program
- Material Safety Data Sheets

Visit www.hp.com/go/environment or www.hp.com/hpinfo/globalcitizenship/environment.

Declaration of Conformity

Declaration of Conformity

according to ISO/IEC 17050-1 and EN 17050-1

Manufacturer's Name: Hewlett-Packard Company DoC#: BOISB-0603-05-rel.1.0

Manufacturer's Address: 11311 Chinden Boulevard

Boise, Idaho 83714-1021, USA

declares, that the product

Product Name: HP LaserJet Professional CM1415fn

Regulatory Model Number²⁾ BOISB-0603-05

BOISB-0903-00 - (US-Fax Module LIU)

BOISB-0903-01 - (EURO-Fax Module LIU)

Product Options: ALL

Print Cartridges: CE320A, CE321A, CE322A, CE323A

conforms to the following Product Specifications:

SAFETY: IEC 60950-1:2005 / EN60950-1: 2006

IEC 60825-1:2007 / EN 60825-1:2007 Class 1 Laser/LED Product)

IEC 62311:2007 / EN 62311:2008

GB4943-2001

EMC: CISPR22:2005 +A1 / EN55022:2006 +A1 - Class B¹⁾

EN 61000-3-2:2006

EN 61000-3-3:1995 +A1 +A2

EN 55024:1998 +A1 +A2

FCC Title 47 CFR, Part 15 Class B1) / ICES-003, Issue 4

GB9254-2008, GB17625.1-2003

TELECOM: ES 203 021; FCC Title 47 CFR, Part 68³⁾

ENERGY USE: Regulation (EC) No. 1275/2008

Supplementary Information:

The product herewith complies with the requirements of the EMC Directive 2004/108/EC and the Low Voltage Directive 2006/95/EC, the R&TTE Directive 1999/5/EC (Annex II), the EuP Directive 2005/32/EC and carries the CE-Marking (accordingly.

This Device complies with Part 15 of the FCC Rules. Operation is subject to the following two Conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- 1. The product was tested in a typical configuration with Hewlett-Packard Personal Computer Systems.
- 2. For regulatory purposes, this product is assigned a Regulatory model number. This number should not be confused with the product name or the product number(s).
- Telecom approvals and standards appropriate for the target countries/regions have been applied to this product, in addition to those listed above.
- 4. This product uses an analog fax accessory module which Regulatory Model numbers are: BOISB-0903-00 (US-LIU) or BOISB-0903-01 (EURO LIU), as needed to meet technical regulatory requirements for the countries/regions this product will be sold.

Boise, Idaho USA

September 2010

For regulatory topics only:

European Contact: Your Local Hewlett-Packard Sales and Service Office or Hewlett-Packard GmbH, Department HQ-

TRE / Standards Europe, Herrenberger Strasse 140, D-71034, Böblingen (FAX:

+49-7031-14-3143) www.hp.com/go/certificates

USA Contact: Product Regulations Manager, Hewlett-Packard Company, PO Box 15, Mail Stop 160, Boise, Idaho

83707-0015 (Phone: 208-396-6000)

Declaration of Conformity (wireless models)

Declaration of Conformity

according to ISO/IEC 17050-1 and EN 17050-1

Manufacturer's Name: Hewlett-Packard Company DoC#: BOISB-0603-06-rel.1.0

Manufacturer's Address: 11311 Chinden Boulevard

Boise, Idaho 83714-1021, USA

declares, that the product

Product Name: HP LaserJet Professional CM1415fnw

Regulatory Model Number²⁾ BOISB-0603-06

BOISB-0903-00 - (US-Fax Module LIU)

BOISB-0903-01 - (EURO-Fax Module LIU)

SDGOB - 0892 - (Radio Module)

Product Options: ALL

Print Cartridges: CE320A, CE321A, CE322A, CE323A

conforms to the following Product Specifications:

SAFETY: IEC 60950-1:2005 / EN60950-1: 2006

IEC 60825-1:2007 / EN 60825-1:2007 Class 1 Laser/LED Product)

IEC 62311:2007 / EN 62311:2008

GB4943-2001

EMC: CISPR22:2005 +A1 / EN55022:2006 +A1 - Class B1)

EN 61000-3-2:2006

EN 61000-3-3:1995 +A1 +A2

EN 55024:1998 +A1 +A2

FCC Title 47 CFR, Part 15 Class B1) / ICES-003, Issue 4

GB9254-2008, GB17625.1-2003

TELECOM: ES 203 021; FCC Title 47 CFR, Part 68³⁾

Radio⁵⁾ EN 301 489-1:V1.8.1 / EN 301 489-17:V1.3.2

EN 300 328: V1.7.1

FCC Title 47 CFR, Part 15 Subpart C (Section 15.247) / IC: RSS-210

ENERGY USE: Regulation (EC) No. 1275/2008

Supplementary Information:

The product herewith complies with the requirements of the R&TTE; Directive 1999/5/EC Annex II and Annex IV, EMC Directive 2004/108/EC, the Low Voltage Directive 2006/95/EC, the EuP Directive 2005/32/EC and carries the CE-Marking () accordingly.

This Device complies with Part 15 of the FCC Rules. Operation is subject to the following two Conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- 1. The product was tested in a typical configuration with Hewlett-Packard Personal Computer Systems.
- 2. For regulatory purposes, this product is assigned a Regulatory model number. This number should not be confused with the product name or the product number(s).
- Telecom approvals and standards appropriate for the target countries/regions have been applied to this product, in addition to those listed above.
- 4. This product uses an analog fax accessory module which Regulatory Model numbers are: BOISB-0903-00 (US-LIU) or BOISB-0903-01 (EURO LIU), as needed to meet technical regulatory requirements for the countries/regions this product will be sold.
- This product uses a radio module device which Regulatory Model number is SDGOB-0892 as needed to meet technical regulatory requirements for the countries/regions this product will be sold.

Boise, Idaho USA

September 2010

For regulatory topics only:

European Contact: Your Local Hewlett-Packard Sales and Service Office or Hewlett-Packard GmbH, Department HQ-

TRE / Standards Europe, Herrenberger Strasse 140, D-71034, Böblingen (FAX:

+49-7031-14-3143) www.hp.com/go/certificates

USA Contact: Product Regulations Manager, Hewlett-Packard Company, PO Box 15, Mail Stop 160, Boise, Idaho

83707-0015 (Phone: 208-396-6000)

Certificate of Volatility

Hewlett-Packard Certificate of Volatility						
Model:	Part Number:		Address: 11311	Chinden	Blvd. Boise, ID. 83714	
CM1415fn	CE861					
CM1415fnw	CE862					
	Volatile Memory					
Does the device contain volati	le memory (I			ower is re	moved)?	
		type, size, functio	n, and steps to clear t			
Type (SRAM, DRAM, etc):	Size:	Function:			Steps to clear memory:	
Synchronous DRAM	128MB	Run-time firmy	vare image, print	Power	off printer	
		job info during	printing			
Type (SRAM, DRAM, etc):	Size:	Function:		Steps to	clear memory:	
	32MB	Page Memory		Power	Power off product / Auto cleared	
					when print job is finished	
Type (SRAM, DRAM, etc):	Size:	Function:		Steps to	clear memory:	
		Non-Volat	ile Memory			
Does the device contain non-	olatile memo			ed when po	ower is removed)?	
☐ Yes ☐ No If Yes please						
Type (Flash, EEPROM, etc):	Size:	Function:	•	Steps to	clear memory:	
EEPROM	16KB	Printer Specific Data		NVRA	NVRAM Initialization	
Type (Flash, EEPROM, etc):	Size:	Function:		Steps to	Steps to clear memory:	
Type (Flash, EEPROM, etc):	Size:	Function: Steps to clear memory:			clear memory:	
SPI FLASH	16MB	Firmware and Fax			,, , .	
	1	Mass	Storage	1		
Does the device contain mass storage memory (Hard Disk Drive, Tape Backup)?						
☐ Yes ☐ No If Yes please describe the type, size, function, and steps to clear the memory below						
Type (HDD, Tape, etc):	Size:	Function:		Steps to	clear memory:	
Type (HDD, Tape, etc):	Size:	Function:		Steps to	Steps to clear memory:	
Author Information						
Name:	Title:	, 101.101 11	Email:		Business Unit:	
	Technical				LaserJet Business	
	Engineer					
			1		Date Prepared: 04/08/2010	

Safety statements

Laser safety

The Center for Devices and Radiological Health (CDRH) of the U.S. Food and Drug Administration has implemented regulations for laser products manufactured since August 1, 1976. Compliance is mandatory for products marketed in the United States. The device is certified as a "Class 1" laser product under the U.S. Department of Health and Human Services (DHHS) Radiation Performance Standard according to the Radiation Control for Health and Safety Act of 1968. Since radiation emitted inside the device is completely confined within protective housings and external covers, the laser beam cannot escape during any phase of normal user operation.

<u>MARNING!</u> Using controls, making adjustments, or performing procedures other than those specified in this user guide may result in exposure to hazardous radiation.

Canadian DOC regulations

Complies with Canadian EMC Class B requirements.

« Conforme à la classe B des normes canadiennes de compatibilité électromagnétiques. « CEM ». »

VCCI statement (Japan)

この装置は、クラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。取扱説明書に従って正しい取り扱いをして下さい。

VCCI-B

Power cord instructions

Make sure your power source is adequate for the product voltage rating. The voltage rating is on the product label. The product uses either 100-127 Vac or 220-240 Vac and 50/60 Hz.

Connect the power cord between the product and a grounded AC outlet.

△ CAUTION: To prevent damage to the product, use only the power cord that is provided with the product.

Power cord statement (Japan)

製品には、同梱された電源コードをお使い下さい。 同梱された電源コードは、他の製品では使用出来ません。

EMC statement (Korea)

B급 기기	이 기기는 가정용(B급)으로 전자파적합등록을 한 기			
(가정용 방송통신기기)	기로서 주로 가정에서 사용하는 것을 목적으로 하			
	며, 모든 지역에서 사용할 수 있습니다.			

Laser statement for Finland

Luokan 1 laserlaite

Klass 1 Laser Apparat

HP LaserJet CM1415fn, CM1415fnw, laserkirjoitin on käyttäjän kannalta turvallinen luokan 1 laserlaite. Normaalissa käytössä kirjoittimen suojakotelointi estää lasersäteen pääsyn laitteen ulkopuolelle. Laitteen turvallisuusluokka on määritetty standardin EN 60825-1 (2007) mukaisesti.

VAROITUS!

Laitteen käyttäminen muulla kuin käyttöohjeessa mainitulla tavalla saattaa altistaa käyttäjän turvallisuusluokan 1 ylittävälle näkymättömälle lasersäteilylle.

VARNING!

Om apparaten används på annat sätt än i bruksanvisning specificerats, kan användaren utsättas för osynlig laserstrålning, som överskrider gränsen för laserklass 1.

HUOLTO

HP LaserJet CM1415fn, CM1415fnw - kirjoittimen sisällä ei ole käyttäjän huollettavissa olevia kohteita. Laitteen saa avata ja huoltaa ainoastaan sen huoltamiseen koulutettu henkilö. Tällaiseksi huoltotoimenpiteeksi ei katsota väriainekasetin vaihtamista, paperiradan puhdistusta tai muita käyttäjän käsikirjassa lueteltuja, käyttäjän tehtäväksi tarkoitettuja ylläpitotoimia, jotka voidaan suorittaa ilman erikoistyökaluja.

VARO!

Mikäli kirjoittimen suojakotelo avataan, olet alttiina näkymättömällelasersäteilylle laitteen ollessa toiminnassa. Älä katso säteeseen.

VARNING!

Om laserprinterns skyddshölje öppnas då apparaten är i funktion, utsättas användaren för osynlig laserstrålning. Betrakta ej strålen.

Tiedot laitteessa käytettävän laserdiodin säteilyominaisuuksista: Aallonpituus 775-795 nm Teho 5 m W Luokan 3B laser.

GS statement (Germany)

Das Gerät ist nicht für die Benutzung im unmittelbaren Gesichtsfeld am Bildschirmarbeitsplatz vorgesehen. Um störende Reflexionen am Bildschirmarbeitsplatz zu vermeiden, darf dieses Produkt nicht im unmittelbaren Gesichtsfeld platziert werden.

ENWW Safety statements 207

Substances Table (China)

有毒有害物质表

根据中国电子信息产品污染控制管理办法的要求而出台

	有毒有害物质和元素					
	铅 汞 镉 六价铬 多溴联苯					多溴二苯醚
部件名称	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)
打印引擎	Χ	0	X	0	0	0
复印机组件	Х	0	0	0	0	0
控制面板	0	0	0	0	0	0
塑料外壳	0	0	0	0	0	0
格式化板组件	Х	0	0	0	0	0
碳粉盒	Х	0	0	0	0	0

3690

0:表示在此部件所用的所有同类材料中,所含的此有毒或有害物质均低于 SJ/T11363-2006 的限制要求。

X:表示在此部件所用的所有同类材料中,至少一种所含的此有毒或有害物质高于 SJ/T11363-2006 的限制要求。

注:引用的"环保使用期限"是根据在正常温度和湿度条件下操作使用产品而确定的。

Restriction on Hazardous Substances statement (Turkey)

Türkiye Cumhuriyeti: EEE Yönetmeliğine Uygundur

Additional statements for telecom (fax) products

EU Statement for Telecom Operation

This product is intended to be connected to the analog Public Switched Telecommunication Networks (PSTN) of European Economic Area (EEA) countries/regions.

It meets requirements of EU R&TTE Directive 1999/5/EC (Annex II) and carries appropriate CE conformity marking.

For more details see Declaration of Conformity issued by the manufacturer in another section of this manual.

However due to differences between individual national PSTNs the product may not guarantee unconditional assurance of successful operation on every PSTN termination point. Network compatibility depends on the correct setting being selected by the customer in preparation of its connection to the PSTN. Please follow the instructions provided in the user manual.

If you experience network compatibility issues, please contact your equipment supplier or Hewlett-Packard help desk in the country/region of operation.

Connecting to a PSTN termination point may be the subject of additional requirements set out by the local PSTN operator.

New Zealand Telecom Statements

The grant of a Telepermit for any item of terminal equipment indicates only that Telecom has accepted that the item complies with minimum conditions for connection to its network. It indicates no endorsement of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance that any item will work correctly in all respects with another item of Telepermitted equipment of a different make or model, nor does it imply that any product is compatible with all of Telecom's network services.

This equipment may not provide for the effective hand-over of a call to another device connected to the same line.

This equipment shall not be set up to make automatic calls to the Telecom "111" Emergency Service.

This product has not been tested to ensure compatibility with the FaxAbility distinctive ring service for New Zealand.

Additional FCC statement for telecom products (US)

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the back of this equipment is a label that contains, among other information, a product identifier in the format US:AAAEQ##TXXXX. If requested, this number must be provided to the telephone company.

The REN is used to determine the quantity of devices, which may be connected to the telephone line. Excessive RENs on the telephone line may result in the devices not ringing in response to an incoming call. In most, but not all, areas, the sum of the RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to the line, as determined by the total RENs, contact the telephone company to determine the maximum REN for the calling area.

This equipment uses the following USOC jacks: RJ11C.

An FCC-compliant telephone cord and modular plug is provided with this equipment. This equipment is designed to be connected to the telephone network or premises wiring using a compatible modular jack, which is Part 68 compliant. This equipment cannot be used on telephone company-provided coin service. Connection to Party Line Service is subject to state tariffs.

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. If advance notice is not practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make the necessary modifications in order to maintain uninterrupted service.

If trouble is experienced with this equipment, please see the numbers in this manual for repair and (or) warranty information. If the trouble is causing harm to the telephone network, the telephone company may request you remove the equipment from the network until the problem is resolved.

The customer can do the following repairs: Replace any original equipment that came with the device. This includes the print cartridge, the supports for trays and bins, the power cord, and the telephone cord. It is recommended that the customer install an AC surge arrestor in the AC outlet to which this device is connected. This is to avoid damage to the equipment caused by local lightning strikes and other electrical surges.

Telephone Consumer Protection Act (US)

The Telephone Consumer Protection Act of 1991 makes it unlawful for any person to use a computer or other electronic device, including fax machines, to send any message unless such message clearly contains, in a margin at the top or bottom of each transmitted page or on the first page of the transmission, the date and time it is sent and an identification of the business, other entity, or individual sending the message and the telephone number of the sending machine or such business, or other entity, or individual. (The telephone number provided cannot be a 900 number or any other number for which charges exceed local or long distance transmission charges).

Industry Canada CS-03 requirements

Notice: The Industry Canada label identifies certified equipment. This certification means the equipment meets certain telecommunications network protective, operational, and safety requirements as prescribed in the appropriate Terminal Equipment Technical Requirement document(s). The Department does not guarantee the equipment will operate to the user's satisfaction. Before installing this equipment, users should ensure that it is permissible for the equipment to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations. Repairs to certified equipment should be coordinated by a representative designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment. Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines, and internal metallic water pipe system, if present, are connected together. This precaution can be particularly important in rural areas.

△ CAUTION: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate. The Ringer Equivalence Number (REN) of this device is 0.0.

Notice: The Ringer Equivalence Number (REN) assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Number of all the devices does not exceed five (5.0). The standard connecting arrangement code (telephone jack type) for equipment with direct connections to the telephone network is CA11A.

Additional statements for wireless products

FCC compliance statement—United States

Exposure to radio frequency radiation

△ CAUTION: The radiated output power of this device is far below the FCC radio frequency exposure limits. Nevertheless, the device shall be used in such a manner that the potential for human contact during normal operation is minimized.

In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20 cm ((8 in)) during normal operation.

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

△ CAUTION: Based on Section 15.21 of the FCC rules, changes of modifications to the operation of this product without the express approval by Hewlett-Packard Company may invalidate its authorized use.

Australia statement

This device incorporates a radio-transmitting (wireless) device. For protection against radio transmission exposure, it is recommended that this device be operated no less than 20 cm from the head, neck, or body.

Brazil ANATEL statement

Este equipamento opera em caráter secundário, isto é, não tem direito à proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário.

Canadian statements

For Indoor Use. This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the radio interference regulations of the Canadian Department of Communications. The internal wireless radio complies with RSS 210 of Industry Canada.

Pour l'usage d'intérieur. Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de Classe B prescribes dans le règlement sur le brouillage radioélectrique édicté par le Ministère des Communications du Canada. Le composant RF interne est conforme à la norme CNR-210 d'Industrie Canada.

European Union regulatory notice

The telecommunications functionality of this product may be used in the following EU and EFTA countries/regions:

Austria, Belgium, Bulgaria, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Liechtenstein, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Romania, Slovak Republic, Slovenia, Spain, Sweden, Switzerland, and United Kingdom.

Notice for use in France

For 2.4 GHz Wireless LAN operation of this product certain restrictions apply: This equipment may be used indoor for the entire 2400-2483.5 MHz frequency band (channels 1-13). For outdoor use, only 2400-2454 MHz frequency band (channels 1-9) may be used. For the latest requirements, see www.arcep.fr.

L'utilisation de cet equipement (2.4 GHz Wireless LAN) est soumise à certaines restrictions : Cet équipement peut être utilisé à l'intérieur d'un bâtiment en utilisant toutes les fréquences de 2400-2483.5 MHz (Chaine 1-13). Pour une utilisation en environnement extérieur, vous devez utiliser les fréquences comprises entre 2400-2454 MHz (Chaine 1-9). Pour les dernières restrictions, voir, www.arcep.fr.

Notice for use in Russia

Существуют определенные ограничения по использованию беспроводных сетей (стандарта 802.11 b/g) с рабочей частотой 2,4 ГГц: Данное оборудование может использоваться внутри помещений с использованием диапазона частот 2400-2483,5 МГц (каналы 1-13). При использовании внутри помещений максимальная эффективная изотропно—излучаемая мощность (ЭИИМ) должна составлять не более 100мВт.

Korean statement

당해 무선설비는 운용 중 전파혼선 가능성이 있음

Taiwan statement

低功率電波輻射性電機管理辦法

- 第十二條 經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者 均不得擅自變更頻率、加大功率或變更原設計之特性及功能。
- 第十四條 低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有 干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。 前項合法通信,指依電信法規定作業之無線電通信。 低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電 機設備之干擾。

Index

Symbols/Numerics	message types 128	dpi (dots per inch)
2ndary service menu 143	messages,	faxing 115
	troubleshooting 128	drawer
A	removing the control panel 22	print-cartridge, removing 14
accessories	conventions, document iii	
ordering 158	copy menu 123	E
acoustic specifications 194	copy-quality test 6	electrical specifications 194
advanced setup	covers	electrostatic discharge (ESD) 4
fax 115	front-lower, removing 36	end-of-life disposal 199
after-service checklist 6	left, removing 25	environmental specifications xi
	rear door and rear-lower cover,	environmental stewardship
В	removing 41	program 197
batteries included 199	rear side, removing 30	error messages
bins, output	rear-upper, removing 31	control panel 128
jams, clearing 142	right, removing 17	event log 133
	right-front, removing 20	ESD (electrostatic discharge) 4
C	top, removing 34	European Union, waste
calibrating color 144	customer support	disposal 199
Canadian DOC regulations 206	online 191	
cartridge	repacking product 192	F
ordering xi		factory defaults, restoring
part number xi	D	NVRAM initialization 145
cartridges	DC controller	factory-set defaults, restoring 144
recycling 197	connectors 105	fax
warranty 187	DC controller PCA, removing 49	answer mode 114
cautions iii	defaults	error codes xi
certificate of volatility 205	NVRAM initialization 145	factory-set defaults,
checklists	defaults, restoring 144	restoring 144
after-service 6	defects, repetitive 103	receiving, troubleshooting xi
preservice 5	diagnostics page	reports 124
checklists, printing 113	printing 109	ring type 114
color	dimensions xi	sending, troubleshooting xi
calibrating 144	disposal, end-of-life 199	fax menu 124
color alignment, calibrating 109	document conventions iii	fax reports, printing 124
connectors	document feeder	fax troubleshooting
DC controller 105	jams 137	fax-quality test 6
control panel	doors	fax-quality test 6
button test 144	front, removing 36	Finnish laser safety
display test 144	rear door and rear-lower cover,	statement 207
menus 111	removing 41	

ENWW Index 215

formatter and fax card PCAs,	M	paper
removing 49	Macintosh	jams 136
front door, removing 36	support 191	paper guide assembly,
front-lower cover, removing 36	main motor	removing 43
fuser	removing 60	paper pickup problems
removing 80	material restrictions 199	solving 135
fuser motor	Material Safety Data Sheet	part number
removing 59	(MSDS) 200	print cartridge xi
· ·	memory	whole-unit replacement xi
G	NVRAM initialization 145	PBX ring detect 144
graph paper, printing 113	memory chip, print cartridge	physical specifications xi
	description 188	pickup roller
H	menu	removing 8
HP Customer Care 191	control panel, access 111	pliers, required 4
HP Jetdirect print server	copy 123	post-service tests 6
NVRAM initialization 145	fax 124	power
humidity specifications	Fax setup 114	consumption 194
environment xi	Network config 122	fuser, removing 77
	Quick Forms 113	high-voltage, removing 67
T. Control of the Con	Reports 112	low voltage, removing 71
image quality	Service 120	preservice checklist 5
repetitive image defects 103	System setup 117	print cartridge
initialization	USB 127	ordering xi
NVRAM 145	menu map, printing 100	part number xi
ITB	mercury-free product 199	print cartridges
reinstalling 65	messages	memory chips 188
removing 62	control panel 128	recycling 197
3	-	warranty 187
J	music paper, printing 113	•
jams	N	print quality
causes of 136	network	repetitive image defects 103
document feeder,	configuring 122	print quality page
clearing 137	Network config menu 122	interpreting 109
locating 136	notebook paper, printing 113	printing 109
output bin, clearing 142	notes iii	print-cartridge drawer,
trays, clearing 139		removing 14
Japanese VCCI statement 206	NVRAM initialization 145	print-quality test 6
Jetdirect print server	0	problem-solving
NVRAM initialization 145	online support 191	control-panel messages 128
TTTT TITLE TO	operating environment,	0
K	specifications xi	Q
Korean EMC statement 207	•	quality
nerean zine etatement zer	ordering	repetitive image defects 103
L	print cartridge xi	B
laser safety statements 206, 207	product documents xi	R
LEDs, troubleshooting 100	supplies and accessories 158	rear door and rear-lower cover,
left cover, removing 25	whole-unit replacement xi	removing 41
license, software 189	output quality	rear side cover, removing 30
location	repetitive image defects 103	rear-upper cover, removing 31
setting 143	P	receiving faxes,
	packaging product 192	troubleshooting xi
	Dackauliu Diouucl 132	

216 Index ENWW

recycling	fax 124	environmental xi
HP printing supplies returns	menu map 112	physical xi
and environmental	network report 112	static precautions 4
program 198	PCL 6 font list 112	storing
reinstalling parts	PCL font list 112	environmental
DC controller PCA 49	print quality page 112	specifications xi
ITB 65	PS font list 112	supplies
removing parts	service 143	ordering 158
cautions for 2	service page 112	recycling 197
checklists 5	supplies status page 112	support
control panel 22	usage page 112	online 191
DC controller PCA 49	resets	repacking product 192
formatter and fax card	NVRAM initialization 145	System setup menu 117
PCAs 49	restoring	Cyclem scrap mena 117
front door 36	default settings 145	Т
front-lower cover 36	NVRAM initialization 145	technical support
		online 191
fuser 80	restoring factory-set defaults 144	repacking product 192
fuser motor 59	right front cover 1 and cover 2	temperature specifications
ITB 62	right-front cover-1 and cover-2,	environment xi
left cover 25	removing 20	tests
main motor 60	rollers	copy-quality 6
order of 7	repetitive image defects 103	
paper guide assembly 43	transfer 12	fax-quality 6
pickup roller 8	6	post-service 6
power supply (fuser) 77	\$	print-quality 6
power supply (high-	safety statements 206, 207	tips iii
voltage) 67	scanner	toner cartridges. See print
power supply (low voltage) 71	assembly, removing 28	cartridges
print-cartridge drawer 14	screwdrivers, required 4	tools, required 4
rear door and rear-lower	screws	top cover, removing 34
cover 41	replacing 2	transfer roller 12
rear side cover 30	secondary service menu 143	trays
rear-upper cover 31	sending faxes, troubleshooting xi	jams, clearing 139
right cover 17	separation rollers	troubleshooting
right-front cover-1 and	removing 10	control panel messages 128
cover-2 20	service	control-panel diagnostics 102
separation roller 10	repacking product 192	jams 136
tools, required 4	tools, required 4	LED diagnostics 100
top cover 34	Service menu	NVRAM initialization 145
USB port 45	secondary 143	paper feed problems 135
repacking product 192	settings	receiving faxes xi
repetitive defects,	factory-set defaults,	sending faxes xi
troubleshooting 103	restoring 144	
replacing	shipping product 192	U
parts 2	size xi	USB menu 127
reports	software	USB port, removing 45
configuration page 112	software license	
demo page 112	agreement 189	V
diagnostics page 112	specifications	volume
error 133, 143	electrical and acoustic 194	settings 117
, =		

ENWW Index 217

W

```
warnings iii
warranty
license 189
print cartridges 187
product 186
Web sites
customer support 191
Macintosh customer
support 191
Material Safety Data Sheet
(MSDS) 200
weight xi
wireless
configuring 122
```

218 Index ENWW

www.hp.com



